

FOR YOUR SAFETY - This product must be installed and serviced by authorized personnel, qualified in pool/spa heater installation. Improper installation and/or operation can create carbon monoxide gas and flue gases which can cause serious injury, property damage, or death. For indoor installations, as an additional measure of safety, Waterpik Technologies strongly recommends installation of suitable Carbon Monoxide detectors in the vicinity of this appliance and in any adjacent occupied spaces. Improper installation and/or operation will void the warranty.

Installation and Operation Manual

LX[®] and LT[®] Low NOx* Gas-Fired Pool and Spa Heater

Model LX/LT-Low NOx* Natural Gas and LP

*Only models using natural gas are certified as meeting low NOx emissions requirements.



Model LX250-L Shown

⚠ WARNING

If these instructions are not followed exactly, a fire or explosion may result, causing property damage, personal injury, or death.

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

Installation and service must be performed by a qualified installer, service agency or the gas supplier.

TABLE OF CONTENTS

SECTION 1. General Information

1.1	Introduction	1
1.2	Consumer Information and Safety	1
1.2.1	Spa/Hot Tub Safety Rules	1
1.2.2	Swimming Pool Energy Safety Tips	2
1.3	Warranty	2
1.4	Codes and Standards	2
1.5	Technical Assistance	3
1.6	Materials Installer Must Provide	3
1.6.1	Materials for All Applications	3
1.6.2	Materials for Special Applications	3
1.7	Specifications	3
1.7.1	General Specifications	3
1.7.2	Dimensions	4

SECTION 2. Installation Instructions

2.1	Introduction	5
2.2	Field Assembly	5
2.3	Location Requirements	5
2.3.1	Introduction	5
2.3.2	Clearances	5
2.3.3	Flooring	6
2.3.4	Outdoor Installation	6
2.3.5	Indoor and Outdoor Shelter Installation	7
2.3.5.1	Converting the Grill to a Vent Collar	8

SECTION 3. Venting

3.1	Combustion Air Supply	8
3.2	Exhaust Venting	9
3.3	Vent Pipe Sizing and General Installation	10
3.3.1	Outdoor Installations	10
3.3.2	Indoor and Outdoor Shelter Installations	10
3.3.3	Inspection and Replacement of Existing Vent System with New Components	11

SECTION 4. Gas Connections

4.1	Gas Supply and Piping	11
4.2	Manifold Pressure	12
4.3	Special Precautions for Propane Gas	13

SECTION 5. Water Connections

5.1	Water Piping	13
5.2	Check Valve Installation	13
5.3	Automatic Flow Control Valve	13
5.4	Reversible Water Connections	14
5.5	Connections at Heater	16
5.6	Pressure Relief Valve	17
5.7	Auxiliary Components, Chlorinators, Ozone Generators, and Sanitizing Chemicals	18

SECTION 6. Electrical

6.1	General Information	18
6.2	Main Power	18
6.2.1	Converting the Heater for a 115V Power Source	20
6.3	Bonding	20
6.4	Auxiliary Time Clock Wiring	21
6.5	Remote Operation	21

SECTION 7. Operating Instructions

7.1	Normal Operation	23
7.2	Start-Up	23
7.3	Temperature Controls	24
7.3.1	Information Displayed	24
7.3.2	Turning the Heater On or Off	25
7.3.3	Setting Pool and Spa Temperatures, Changing from Fahrenheit to Celsius	26
7.4	Lighting and Shutdown Procedures	26
7.4.1	Lighting the Heater	26
7.4.2	Shut Down	26
7.5	Adjusting the Water Pressure Switch	28
7.6	Temperature Rise	29

SECTION 8. Maintenance

8.1	Water Chemistry	30
8.2	Seasonal Care	30
8.2.1	Spring and Fall Operation	30
8.2.2	Winterizing	30
8.2.3	Spring Start-up	31
8.3	Inspection and Service	31
8.3.1	Owner Inspection	31
8.3.2	Professional Inspection	32

SECTION 9. Troubleshooting

9.1	General Heater Troubleshooting Guide	32
9.2	Service Codes	33
9.3	Ignition Control LED Service Codes	33

SECTION 10. Professional Maintenance and Service

10.1	General Information	36
10.2	"Premix" Induced Draft Combustion System	36
10.3	Special Service Issues	
	Premix Combustion System	37
10.3.1	System Operation	37
10.3.2	Field Service and Adjustment	37
10.4	Heater Components and Their Operation	38
10.5	Electrical Trouble Shooting	38
10.5.1	Electrical Power Supply	39
10.5.2	Controller	39
10.5.3	Control Circuit Trouble Shooting	39
10.5.3.1	Transformer	40
10.5.3.2	Fuse	40
10.5.3.3	Water Pressure Switch/External Interlock or Fireman Switch Circuit	40
10.5.3.4	Temperature Limit Switches Circuit	40
10.5.3.5	Fusible Link/Manual Reset Limit Switch Circuit	41
10.5.3.6	Blower Pressure Switch Circuit	41
10.5.3.7	Gas Valve Voltage	42
10.5.3.8	Igniter/Ignition Control Circuit	42

SECTION 11. Replacement Parts

11.1	Ordering Information	46
11.2	Parts List	47
11.3	General Exploded View	48
11.4	Detailed Exploded View	49
	Warranty	Back Cover

SECTION 1. General Information

1.1 Introduction

This manual provides installation and operation instructions for the LX and LT Low NOx pool and spa heaters. Read these installation and operation instructions completely before proceeding with the installation. Consult the Jandy factory, or local factory representative, with any questions regarding this equipment.


Certain sections of this manual are specific to either United States or Canadian installations, and are labeled as such.

The LX and LT Low NOx heaters get their electrical power from an external 115VAC or 230VAC source and provide a dual electronic thermostat control system for pool/spa combinations or preheat convenience.

The LX and LT Low NOx heaters are specifically designed for heating fresh water swimming pools and spas, and with proper installation and care, they will provide years of reliable service. Do not use the heater to maintain pool or spa water temperature below 70°F. Do not use it as a heating boiler or general service water heater or to heat salt water. Consult your dealer for the appropriate Jandy products for these applications.

In the LX and LT heaters, low NOx operation is achieved through use of a special “premix” combustion system. The operation of this type of system is affected by fuel gas properties. As noted in the troubleshooting and maintenance sections of this manual, adjustments may be necessary if the local gas supply is of especially high or low heat content.

1.2 Consumer Information and Safety

The LX and LT Low NOx heaters are designed and manufactured to provide many years of safe and reliable service when installed, operated and maintained according to the information in this manual and the installation codes referred to in later sections. Throughout the manual safety warnings and cautions are identified by the “” symbol. Be sure to read and comply with all of the warnings and cautions.

1.2.1 Spa/Hot Tub Safety Rules

WARNING

The following “Safety Rules for Hot Tubs,” recommended by the U.S. Consumer Product Safety Commission, should be observed when using the spa.

AVERTISSEMENT

Les Règlements suivants pour Cuves Thermales, tel que recommandés par la Commission U.S. de Sécurité des Produits pour les Consommateurs, devraient être respectés lors de l'utilisation du spa.

WARNING

The U.S. Consumer Product Safety Commission warns that elevated water temperature can be hazardous. Consult heater operation and installation instructions for water temperature guidelines before setting temperature.

AVERTISSEMENT

La U.S. Consumer Product Safety Commission indique que des températures de l'eau élevées peuvent être dangereuses. Voir la notice d'installation et de fonctionnement pour le réglage de la température.

1. Spa or hot tub water temperature should never exceed 104°F (40°C). One hundred degrees Fahrenheit (100°F [38°C]) is considered safe for a healthy adult. Special caution is recommended for young children.
2. The drinking of alcoholic beverages before or during spa or hot tub use can cause drowsiness which could lead to unconsciousness, and subsequently result in drowning.
3. **Pregnant women take note!** Soaking in water above 102°F (38.5°C) can cause fetal damage during the first three months of pregnancy (which could result in the birth of a brain-damaged or deformed child). If pregnant women are going to use a spa or hot tub, they should make sure the water temperature is below 100°F (38°C) maximum.
4. The water temperature should always be checked with an accurate thermometer before entering a spa or hot tub. Temperature controls may vary by as much as 1F° (1C°).
5. Persons with a medical history of heart disease, diabetes, circulatory or blood pressure problems should consult their physician before using a hot tub or spa.
6. Persons taking any medication which induces drowsiness (e.g., tranquilizers, antihistamines, or anticoagulants) should not use spas or hot tubs.
7. Prolonged immersion in hot water can induce hyperthermia.

Hyperthermia occurs when the internal body temperature reaches a level several degrees above the normal body temperature of 98.6°F (37°C). Symptoms include dizziness, fainting, drowsiness, lethargy, and an increase in the internal body temperature. The effects of hyperthermia include:

- Lack of awareness of impending hazard
- Failure to perceive heat
- Failure to recognize need to leave spa
- Physical inability to leave spa
- Fetal damage in pregnant women
- Unconsciousness resulting in a danger of drowning

1.2.2 Swimming Pool Energy Saving Tips

Waterpik Technologies offers the following recommendations to help conserve fuel and minimize the cost of operating your pool heater without sacrificing comfort.

1. The American Red Cross recommends a maximum water temperature of 78°F (25°C). Use an accurate pool thermometer. A difference of 4F° (2°C), between 78°F and 82°F (26°C and 28°C), will use as much as 40% more gas.
2. Carefully monitor the water temperature of your pool in the summertime. You can reduce heater usage due to warmer air temperatures.
3. Find the proper setting on the pool heater temperature control and use the locking ring to discourage further adjustments. (LT only).
4. Set the pump time clock to start the pump no earlier than 6:00 AM during the pool heating season. This is the time when nightly heat loss balances.
5. If the pool is only going to be used on weekends, reduce the heater temperature control setting by 8 or 10 degrees during the week. Reset it to the 78°F (25°C) level a day or so before you plan to use the pool.
6. During the winter or when on vacation for longer than a week, shut down the heater by following the shutdown instructions found on the inside of the heater.
7. Where possible, shelter the pool from prevailing winds with well-trimmed hedges or other landscaping, cabanas, or fencing.
8. Always use a pool cover when practical. Besides providing a valuable safety feature, a pool cover will reduce heat loss, conserve chemicals, and reduce the load on filter systems.

1.3 Warranty

The LX and LT Low NOx heaters are sold with a limited factory warranty. Details are specified on the back cover of this manual.

Make all warranty claims to an authorized Jandy representative or directly to the factory. Claims must include the heater serial number and model (this information can be found on the rating plate), installation date, and name of the installer. Shipping costs are not included in the warranty coverage.

The warranty does NOT cover damage caused by improper assembly, installation, operation or field modification. Also, damage to the heat exchanger by corrosive water is NOT covered by the warranty. See Section 8.1 for maintaining proper pool water chemistry.

NOTE: Keep this manual in a safe place for future reference when inspecting or servicing the heater.

1.4 Codes and Standards

The LX and LT Low-NOx pool and spa heaters are design certified by CSA (Canadian Standards Association) as complying with the latest edition of the "Standard for Gas Fired Pool Heaters", ANSI Z21.56 in the USA and CAN-4.7 in Canada.

All Jandy heaters must be installed in accordance with the local building and installation codes as per the utility or authorities having jurisdiction. All local codes take precedence over national codes.

In the absence of local codes, refer to the latest edition of the following national codes for installation:

1. In the United States, "The National Fuel and Gas Code", NFPA 54/ANSI Z223.1. Specifically, refer to Part 7, "Venting of Equipment".
2. In Canada, "Natural Gas and Propane Installation Code", CAN/CSA-B149.1.

The LX and LT Low NOx pool and spa heaters exceed the requirements of energy conservation regulations such as those in California, Hawaii, New York, Oregon and other states which require that a pool heater have intermittent ignition. In addition, the natural gas models of this heater comply with both the California South Coast Air Quality Management District's (SCAQMD) rule 1146.2 and the Title 30, Texas Administrative Code, Chapter 117, Section 117.465 for Nitrogen Oxide (NOx) emissions.

Any changes to the heater, gas controls, gas orifices, wiring, draft diverter, or improper installation may void the warranty. If change is required to any of the above, consult the factory.

1.5 Technical Assistance

Consult Waterpik Technologies or your local Jandy distributor with any questions or problems involving the specifications, installation, and operation of your Jandy equipment. An experienced technical support staff is ready to assist you in assuring the proper performance and application of Jandy products. For technical support call the Technical Service Department at (707) 776-8200 extension 260.

1.6 Materials Installer Must Provide

1.6.1 Materials for All Applications

The following items are needed and are to be supplied by the installer for *all* LX/LT Low NOx heater installations:

1. The correct size gas pipe to supply gas from the meter to the heater (see Section 4.1).
2. A manually operated gas valve to be installed in the gas line outside of the heater jacket.
3. A suitable gas union joint to connect the heater to the gas line outside of the heater.
4. Plumbing items needed to provide a sediment trap (drip leg) in the gas line between the manual gas valve and the heater (see Section 4.1).
5. A 115V AC or 230V AC power supply. A junction box is not needed at the heater, connections are made inside of the heater jacket.

1.6.2 Materials for Special Applications

In addition to the items listed above, the following items are needed for special applications.

1. A factory authorized vent collar and any vent pipe needed for indoor installations in the USA and outdoor shelter installations in Canada (see Section 3.3.2). Vent collars are available from any Jandy distributor.
2. Primer and cement suitable for cementing CPVC pipe to PVC pipe and an appropriate coupling for connecting the factory supplied CPVC pipe nipples to PVC pool plumbing.
3. A non combustible platform for installation on combustible surfaces (see Section 2.3.3). Non combustible bases are available from your Jandy distributor.

1.7 Specifications

1.7.1 General Specifications

1. Installation Location:
Certified for use:
In the USA:
Natural Gas: Indoor and Outdoor
LP: Indoor and Outdoor
In Canada:
Natural Gas : Outdoor and Outdoor Shelter
LP: Outdoor and Outdoor Shelter
2. Minimum Clearance From Combustible Material:
See Table 2 in Section 2.3.2
3. *Gas Pipe/Heater Gas Valve Connection:
Natural Gas: 3/4" NPT
LP: 3/4" NPT
*For diameter of gas line from meter to heater see Table 5 in Section 4.1.
4. Supply Gas Type:
Certified for use with:
Natural gas and LP
5. Inlet Gas Supply Pressure:

	Minimum	Maximum
Natural Gas:	5.0 "WC	10.5 "WC
LP:	10.0 "WC	14.0 "WC
6. Water Pipe/Heater Connection:
*2" Unthreaded PVC or CPVC
*Other size pipes may be used. See Section 5.5 for details
7. Water Flow Rate:
Maximum: 125 gpm (475 lpm)
Minimum: 30 gpm (110 lpm)
8. Working Water Pressure:
Maximum: 75 psi
9. Exhaust Vent Connection Size:
Model:
250 7" Diameter
400 9" Diameter
10. Electrical Supply:
Either 115 Volts AC or 230 Volts AC.
11. Modification of Heater for High Altitude:
LX and LT Low-NOx are normally shipped from the factory in the low altitude (sea level) operational configuration. When requested, the heaters can be configured and shipped for higher altitudes. For field conversions to change altitude configurations, manifold kits for mid altitudes and

high altitudes are available from your Jandy pool products dealer or by contacting the Customer Service Department at 707.776.8200 extension 245. See Section 11, "Parts List", of this manual for the correct kit number for the manifold assembly needed for your altitude. Table 1 defines the altitude designations as described by the "Standard for Gas Fired Pool Heaters", ANSI Z21.56 in the United States and "Gas-Fired Appliances For Use At High Altitudes", CAN1-2.17 in Canada.

1.7.2 Dimensions

See Figure 1 for a diagram showing the heater's exterior dimensions and dimensions to critical connections on the heater.

Table 1. Altitude Designations For The LX/LT Heaters

NATURAL GAS		
ALTITUDE DESIGNATION	UNITED STATES	CANADA
LOW ALTITUDE	0-3000 FT	0-2000 FT (0-610 m)
MID ALTITUDE	3001-6000 FT	2001-4500 FT (611-1370 m)
HIGH ALTITUDE	6001-10,000 FT	NOT APPLICABLE
LP		
LOW ALTITUDE	0-5000 FT	0-4500 FT (0-1370 m)
HIGH ALTITUDE	5001-10,000 FT	NOT APPLICABLE




Figure 1. General Configuration

SECTION 2. Installation Instructions

2.1 Introduction

⚠ WARNING

Improper installation or maintenance can cause nausea or asphyxiation from carbon monoxide in flue gases which could result in severe injury, or death. For indoor installations, as an additional measure of safety, Waterpik Technologies strongly recommends installation of suitable Carbon Monoxide detectors in the vicinity of this appliance and in any adjacent occupied spaces.

⚠ AVERTISSEMENT

Une installation ou un entretien inadéquat peut causer la nausée ou l'asphyxie en raison du monoxyde de carbone présent dans les gaz de combustion et même entraîner des blessures graves ou la mort. Pour les installations intérieures, comme mesure de sécurité additionnelle, Waterpik Technologies recommande fortement l'installation de détecteurs de monoxyde de carbone près de cet appareil ainsi que dans les espaces adjacents occupés.

Install the LX and LT Low NOx heaters and vent collars in accordance with the procedures in this manual, local codes and ordinances, and in accordance with the latest edition of the appropriate national code (see Section 1.4 "Codes and Standards").

All gas-fired products require correct installation to assure safe operation. The requirements for pool heaters include the following:

1. Field assembly (if required)
2. Appropriate site location (clearances) and flooring
3. Sufficient combustion and ventilation air
4. Properly sized gas meter and piping
5. Proper electrical wiring (if required)
6. Adequate water flow

This manual provides the information needed to meet these requirements. Review all application and installation procedures completely before continuing the installation.

2.2 Field Assembly

The LX and LT Low NOx heaters can be installed in a variety of ways, some of them requiring preparation or assembly in the field. The heater is shipped from the factory with an exhaust vent configured for an outdoor installation. The LX and LT Low NOx heaters are also design certified for "Indoor" installations in the United States and "Outdoor Shelter" installations in Canada when equipped with a vent collar and the appropriately sized exhaust vent.

Check the rating plate on the heater or the Parts List (Section 11.2) of this manual for the correct Jandy vent collar part number. For specific installation information see Section 2.3.5 "Indoor and Outdoor Shelter Installations".

Water connections are provided on the right side of the heater but can be changed to the left side by reversal of the heat exchanger. It is best to handle these preparations before the heater is installed in its final location. See Section 5.4 "Reversible Water Connections" of this manual for instructions.

2.3 Location Requirements

2.3.1 Introduction

⚠ CAUTION

When pool equipment is located below the pool surface, a leak from any component can cause large scale water loss or flooding. Waterpik Technologies cannot be responsible for such water loss or flooding or resulting damage.

⚠ ATTENTION

Lorsque l'équipement d'une piscine est situé sous la surface de l'eau, une fuite provenant de n'importe quel élément peut causer une perte d'eau importante ou une inondation. Waterpik Technologies n'est pas responsable des pertes d'eau, des inondations ou des avaries causées par une installation ou un entretien inadéquat.

The LX and LT Low NOx heaters may be installed indoors or outdoors as outlined in later sections. Location of the heater below *or above* the pool water level affects operation of its water pressure switch. See sections on water piping and heater start-up for more information about this.

Avoid placing the heater in locations where it can cause damage by water or condensate leakage. If this is not possible, provide a suitable drain pan to catch and divert any leakage. The pan must not restrict the air flow around the heater.

All criteria given in the following sections reflect minimum clearances as stated in the national standards. However, each installation must also be evaluated, taking into account the prevailing local conditions such as wind speed and direction, proximity and height of walls that may block ventilation, and proximity to public access areas.

2.3.2 Clearances

The heater must be placed to provide clearances on all sides for maintenance and inspection. There must also be minimum distances maintained from combustible surfaces (see Table 2).

At least 18" (457mm) access must be available in front of the heater for burner removal and access to the igniter.

If the heater is to be installed in a garage, or

Table 2. Minimum Heater Clearances From Combustible Surfaces
Table 2. Dégagements Minimaux à Assurer Entre les Parois de L'appareil et les Constructions Combustibles

SIDE OF HEATER	INDOOR (OUTDOOR SHELTER) INSTALLATION		OUTDOOR INSTALLATION	
	INCHES	CENTIMETERS	INCHES	CENTIMETERS
BLANK	4	10.2	4	10.2
REAR	4	10.2	4	10.2
PIPING	12	30.5	12	30.5
TOP	39	99.0	OPEN UNROOFED AREA	
FRONT	18*	45.7	18*	45.7

Note: Clearances listed in Table 2 are manufacturer's tested values. These are given as minimum values. Where local and national codes apply, and values are different than those listed in Table 2, use the greater value to ensure safe operation.

* In Canada - 24 in (61cm)

similar structure, all burners and burner ignition devices must have a minimum 18" (457mm) clearance above the floor.

This heater must be installed at least 5 feet (1.52m) from the inside wall of a pool unless the heater is separated from the pool by a solid fence, wall or other permanent solid barrier.

Ce chauffe-piscine doit être installé à au moins 5 pieds (1.52m) de la paroi interne de la piscine à moins d'être isolé de la piscine par une clôture, un mur ou autre barrière permanente.

2.3.3 Flooring

The heater must be installed on a **level** surface of noncombustible construction or on fire-resistant slabs or arches. Noncombustible flooring is defined as flooring material and surface finish not capable of being ignited and burning and with no combustible materials against the underside. Acceptable materials are those consisting entirely of a combination of steel, iron, brick, tile, concrete, slate, glass or plaster. **Do not** install the heater directly on a combustible wood or carpet floor without placing a noncombustible platform between the floor and the heater.

The heater can be installed on a combustible floor if a noncombustible base assembly, available from Jandy, is used. See the heater rating plate or the Parts List (Section 11) of this manual for the appropriate base part number. **Heaters must never be installed directly on carpeting.**

As an alternative to the Jandy noncombustible base plate, in the United States, the National Fuel Gas Code (NFPA 54 / ANSI Z223.1), and in Canada, the Natural Gas and Propane Installation Code (CAN/CSA-B149.1), allow a heater to be placed on a combustible surface when there is a platform under the heater made of hollow masonry no less than 4 inches (102 millimeters [mm]) thick, covered with sheet metal at least 24 gauge thick and extending beyond the full width and depth of the heater by at least 6 inches (153 mm) in all directions. The masonry




Figure 2. Non-Combustible Platform

must be laid with ends unsealed, and joints matched to provide free circulation of air from side to side through the masonry (see Figure 2). If the heater is installed in a carpeted alcove, the entire floor of the alcove must be covered by a noncombustible panel.

2.3.4 Outdoor Installation

The LX or LT Low NOx heaters can be installed in the outdoor configuration as received from the factory.

Locate the heater in an **open, unroofed area**. Do not install the heater under a deck. Do not locate the heater below or adjacent to any doors, glass openings, louvers, grills, etc., which connect in any way with an inhabited area of a building, even though the access might be through another structure (e.g., a garage or

utility room). In the United States there must be a minimum of four (4) feet (1.22 m) horizontally **and** four (4) feet (1.22 m) vertically between the heater exhaust point and any door, glass opening, or gravity inlet to a building. In Canada, the heater must be installed so that the exhaust point of the heater is at least ten (10) feet (3.0 m) from any building opening (see Figure 3).

⚠ WARNING
<p style="text-align: center;">United States</p> <p>Do not install the heater with the top of the vent assembly within 4 feet (1.22 m) horizontally and 4 feet (1.22 m) vertically of any opening into a building.</p>
<p style="text-align: center;">Canada</p> <p>Do not install the heater with the top of the vent assembly within 10 feet (3.05 m) of any opening into a building.</p>
⚠ AVERTISSEMENT
<p>Lorsque vous installez l'appareil de chauffage, assurez-vous que l'ouverture d'aération se trouve à un minimum de 10 pieds (3,05 m) de toute ouverture d'un bâtiment.</p>

The top surface of the heater must be at least three(3) feet above any forced air inlet, or intake ducts located within ten(10) feet horizontally.

If the heater is installed under an overhang, there must be a minimum clearance of 5 feet (1.5 m) above the top of the heater and the structure should not overhang the heater more than 12 inches (0.30m). The area under the overhang must be open on three sides. This prevents combustion gases from being diverted into living areas through doors, windows, or gravity inlets.




Figure 3. Outdoor Heater Installation

Ne pas installer ce chauffe-piscine sous une saillie mesurant moins de 3 pi de hauteur. La partie sous la saillie doit être ouverte sur 3 côtés.

If the heater is installed close to a structure, protect it from rain water runoff with rain gutters on the roof or other measures. Do not locate the heater near irrigation sprinkler systems that could spray water on it. Water from sprinklers may cause damage to controls and electronic components.

Avoid locations where wind deflection off nearby structures might cause downdraft conditions. Where downdraft conditions exist, locate the heater at least 3 feet (0.91 m) from vertical surfaces (e.g., nearby buildings and walls).

In Florida it is required that the heater be securely fastened to the equipment pad. Use a size 1/4" x 1-1/2" long stainless steel Tapcon® type concrete screws and washers at each of the four tabs located at the base of the heater. Mounting the appliance in this manner meets the applicable requirements of the Florida Building Code.

Mounting screws are not provided with this heater. After placing the heater on the equipment pad, drill a hole in the concrete at each of the four tabs on the feet of the heater. (The correct size drill bit is usually provided with the concrete screws when purchased). Place a screw in each of the holes and fasten the heater to the equipment pad (see Figure 4).

Do not over torque the screws.




Figure 4. Anchor Heater To Equipment Pad

2.3.5 Indoor and Outdoor Shelter Installations

An outdoor shelter (Canada only) is an unoccupied enclosure which does not communicate directly with occupied areas. All indoor installations and outdoor shelter installations require the addition of a factory approved vent collar. The vent collar must be installed without modification and in accordance with the instructions provided by the manufacturer.

Une remise extérieure (au Canada seulement) est un endroit inoccupé qui ne communique pas directement avec les endroits occupés. Toutes les installations intérieures et remises extérieures exigent l'addition d'une cheminée approuvée par le fabricant. La cheminée doit être installée sans aucune modification et selon les exigences fournies par le fabricant.

These codes, standards and Waterpik Technologies require that the heater be properly vented as outlined in this manual. Proper ventilation of exhaust and combustion air are essential for the safe and efficient operation of the heater (See Section 3).




Figure 5. Removal of Outdoor Exhaust Grill




Figure 6. Vent Collar Assembly for Indoor and Outdoor Shelter Installation




Figure 7. Vent Pipe Installation

2.3.5.1 Converting the Grill to a Vent Collar

If the LX or LT Low NOx is to be installed either indoors or in an outdoor shelter, its exhaust discharge grill must be converted to a collar for vent pipe connection. The necessary vent collar, gasket and screws can be ordered as parts kit R0331403 for model 250 or R0331405 for model 400 (see parts list in Section 11 of this manual). The conversion can be done quite simply as follows:

1. Remove the vent exhaust grill by removing the four screws which retain it. The grill and the screws may be discarded (See Figure 5).
2. Replace the grill with the vent collar. Place the vent collar and gasket over the hole and fasten it in place with the 4 screws provided. Be sure that all components are properly aligned (See Figure 6).
3. Install the vent pipe on the indoor vent collar. The collar will accommodate vent piping of nominal 7" or 9" diameter (see Table 4), depending upon the model of your heater (See Figure 7). See vent installation section for important information on selecting proper pipe size.

SECTION 3. Venting

3.1 Combustion Air Supply

The heater location must provide sufficient air supply for proper combustion and ventilation of the surrounding area as outlined in the latest edition of ANSI standard Z223.1 or in Canada, CAN/CSA-B149.1, and any local codes that may be applicable.

In general, these requirements specify that the room in which a heater is installed should be provided with two permanent air supply openings; one within 12 inches (305mm) of the ceiling, the other within 12 inches (305mm) of the floor. All indoor installations must have openings to outside air for combustion, ventilation, and dilution of flue gases from inside the building (see Figure 7 and Table 3). Waterpik Technologies does not recommend indoor installations that do not provide combustion air from outside the building.

All outdoor shelter installations (Canada only) must have uninterrupted openings to outside air for combustion and ventilation. The installation must be in accordance with the latest edition of CAN/CSA B149. Waterpik Technologies does not recommend outdoor shelter installations that depend on internal air for combustion. Combustion air should be ducted to the heater from outside the structure.




Figure 8. Indoor Installation Venting (USA), or Outdoor Shelter (Canada)

Table 3. Air Openings to Outside

Model	Required Net Free Open Area* for Combustion Air Openings		Duct from outside	
	Direct from outside	Duct from outside	in ²	cm ²
250-L	63	(406)	126	(813)
400-L	100	(645)	200	(1290)

*Area indicated is for one of two openings; one at floor level and one at the ceiling, so the total net free area would be double the figures indicated. For special conditions, refer to NFPA54 ANSI Z223.1. **In Canada refer to the National Standard CAN/CSA-B149.1 which differs from this table.**

Note: If using screens and/or metal louvers, compensate by adding 50% additional area to each opening

If using wood louvers each opening must be at least four times the area indicated in the table above.

Outside Air Supply: When combustion air is supplied directly through an outside wall, each opening should have a minimum free area of one square inch per 4,000 BTU/h (1.2kW) input of the total input rating of all appliances in the enclosed area. If air is provided through horizontal ducts, each opening and duct must provide one square inch of flow area for each 2000 BTU/h (0.6 kW). These requirements are summarized in Table 3. Note that the areas specified are net free areas and should be increased when the openings are covered by screens, louvers, grills or other protective covers (see Figure 8 and Table 3 notes).

Note: In Canada, follow Canadian Standard, CAN/CSA-B149.1 or local codes.

Exhaust Fans or Vents: Any equipment which exhausts air from the room where the heater is installed can deplete the combustion air supply or reverse the natural draft action of the venting system. This could cause flue products to accumulate in the room. Additional air must be supplied to compensate for such exhaust.

The information in Table 3 is not applicable in installations where exhaust fans or blowers of any type are used. Such installations must be designed by qualified engineers.

The heater must be completely isolated and protected from any source of corrosive chemical fumes such as those emitted by trichlorethylene, perchloroethylene, chlorine, etc.

⚠ WARNING

Do not store any chemicals, cleaners, or other corrosive material near combustion air openings or in the room. Avoid locating appliance vents in the vicinity of combustion air openings. Failure to prevent corrosive materials from mixing with combustion air can result in reduced heater life and unsafe heater operation.

⚠ AVERTISSEMENT

Ne pas entreposer ni utiliser d'essence ni d'autres vapeurs ou liquides inflammables à proximité de cet appareil ou de tout autre appareil.

3.2 Exhaust Venting

When converted to indoor and outdoor shelter venting configuration, the LX and LT Low NOx heaters have a vent collar fitting. The diameter of the vent collar and, thus, the minimum diameter of the vent pipe to be used is determined by the model of heater installed. **The only correct procedure for vent pipe sizing is to do so in accordance with Table 4 and the applicable installation code as stated in the following "Danger" warning.**

Table 4. Vent Pipe Sizing Table

LX/LT Low NOx Model	Vent Pipe Diameter	
	inch	cm
250-L	7.0	17.8
400-L	9.0	22.9

⚠ WARNING

Vent pipe diameter must be as required by the National fuel Gas Code Z223.1 or the Canadian Installation Codes for Gas Appliances CAN/CSA-B149.1. Undersize pipe can result in inadequate venting and oversize pipe can result in vent condensation. In either case the result can be release of combustion products to the indoors. This can cause serious injury or death by carbon monoxide poisoning or asphyxiation.

⚠ AVERTISSEMENT

Le diamètre des tuyaux de ventilation doit répondre aux exigences du *National Fuel Gas Code* Z223.1 ou du code canadien des installations des appareils à gaz CAN/CSA B149.1. Des tuyaux trop petits risquent d'entraîner une ventilation inadéquate et des tuyaux trop gros risquent de provoquer une condensation dans les tuyaux. Dans un cas comme dans l'autre, des produits de combustion risquent de s'échapper dans le bâtiment et causer des blessures graves ou l'asphyxie par le monoxyde de carbone.

3.3 Vent Pipe Sizing and General Installation

As part of their certification, the LX and LT Low NOx heaters have been determined to be a Category 1 Fan-Assisted appliance. They are intended for standard vertical venting per tables provided in most local codes for Category 1 Fan-Assisted appliances. If the local code does not include such tables, refer to the National Fuel Gas Code NFPA 54 / ANSI Z223.1 or the Canadian Installation Codes for Gas Appliances CAN/CSA-B149.1. Note that the tables for fan-assisted appliances include both maximum and minimum vent loading figures. The primary purpose of the maximum ratings are to assure that the vent operates with negative pressure throughout its length. The minimum ratings are to assure that vent gases don't cool too much and thereby assure that condensation doesn't occur.

3.3.1 Outdoor Installations

For outdoor installations, exhaust venting considerations will determine the placement of the heater (See Section 2.3.4). If the heater cannot be placed so as to meet the requirements stated in Section 2.3.4, a vent collar may be added to the heater to move the exhaust vent opening to a position that complies with

the requirements. In all cases, vent collars must be of the same diameter as the exhaust outlet of the heater. Approved vent collars may be obtained through your Jandy distributor.

3.3.2 Indoor and Outdoor Shelter Installations

All indoor installations and outdoor shelter installations require the addition of a factory approved vent collar. The vent collar must be installed without modification.

All vent installations must be made in accordance with all local, state or provincial codes and with:

- Chapter 7, "Venting of Equipment" of the national Fuel Gas Code, ANSI 223.1 latest edition, or the applicable provisions of the local building codes.

- In Canada, CAN/CSA B149.1.

Avoid terminating heater vents near air conditioning or air supply fans. The fans can pick up exhaust flue products from the heater and return them inside the building, creating a possible health hazard.

Do not locate the vent terminal where flue products could strike against building materials and cause degradation.

Vent opening should be well away from trees or other obstructions that would prevent free air flow to and from vent terminal. Do not terminate the vent under decks, stairways, or car ports.

Be sure to support all venting so that connections will not separate and so that the weight of the vent pipe does not rest on the heater vent collar. All connections should be made with rustproof sheet metal screws. Do not weld or fasten the vent pipe to the heater vent collar. The vent collar and heater top must be easily removable for normal heater service and inspection.

The vent collar outlet is to be connected to an unobstructed vent pipe of the same diameter, terminating outside the building. The vent must terminate at least two (2) feet (0.6 m) above the highest point of the roof or other object that is within ten (10) feet (3.0 m) of the vent termination. The vent pipe must have a listed vent cap which allows a full equivalent opening for flue products (see Figure 7).

Type "B" double wall or equivalent vent pipe is recommended. However, single wall metal vent pipe may be used as specified in the latest edition of the National Fuel Gas Code ANSI Z 223.1 or in Canada CAN/CSA-B149.1.

IMPORTANT NOTE: Do not use sheet metal screws at the snap lock joints of Type B gas vents.

When venting multiple appliances through one common duct, each appliance must have its own vent temperature limit switch. All vent limit switches must be wired in series so as to prevent any appliance from firing in the event of a blocked vent. Refer to ANSI Z223.1 or, in Canada, to CAN/CSA B149.1 for more information on multiple venting.

3.3.3 Inspection and Replacement of Existing Vent System with New Components

If the LX/LT is being installed to replace an existing pool heater, it is recommended that a new appropriate venting system be installed with the new heater. However, if an existing venting system must be used, be sure to carefully inspect the venting system to ensure that it is in good condition and continues to be appropriate for the LX/LT heater. Replace any parts that are not in good and serviceable condition with new parts before completing the pool heater installation.

SECTION 4. Gas Connections

4.1 Gas Supply and Piping

Review the following general instructions before continuing the installation.

⚠ WARNING

The LX and LT Low-NOx pool and spa heaters are designed for use with either natural gas or LP gas. Check the rating plate on the inner panel to be sure that the heater is designed to use the type of gas being supplied. **DO NOT ATTEMPT TO CONVERT THIS HEATER FOR USE WITH ANY OTHER TYPE OF FUEL.**

⚠ AVERTISSEMENT

Les appareils de chauffage à faibles émissions NOx LX et LT pour piscines et cuves thermales sont conçus pour être utilisés avec du gaz naturel ou du gaz de pétrole liquéfié (GPL). Vérifiez l'information inscrite sur la plaque signalétique du panneau intérieur pour vous assurer que l'appareil est conçu pour le type de gaz fourni. **NE PAS ESSAYER DE CONVERTIR CET APPAREIL À UN AUTRE TYPE DE GAZ.**

- Gas piping installation must be in accordance with the latest edition of ANSI Z223.1 and all local codes. In Canada, the installation must be in accordance with CAN/CSA B149.1 and all local codes that apply.
- Check the gas supply to be sure that it is the same as the gas indicated on the heater's rating plate. LX and LT Low NOx heaters, as shipped from the factory, are certified to operate within the altitude range indicated on the rating plate. If a field conversion to a different altitude range should be necessary, manifold kits are available for changing the altitude range of the heater. See Table 1 on page 4 of this manual to determine the correct altitude designation for your heater. Refer to Section 11 "Parts List" to order the

correct part number of the manifold kit needed. When changing the altitude range of the heater, be sure to fill out the altitude conversion label, included in the kit. Apply the label on the inner panel of the heater, next to the original rating plate.

⚠ CAUTION

Permanent damage to the gas valve will occur if the following procedures are not followed.

⚠ ATTENTION

Vous endommagerez la soupape de gaz si vous ne respectez pas les procédures suivantes.

- Use the figures in Table 5 to size the gas inlet piping from the gas meter to the heater. Check all local codes for compliance before installing the heater.

Table 5. Supply Gas Pipe Size Requirements*

Heater Size	Distance from Gas Meter					
	0-50 feet (0-15 m)		50-100 feet (15-30 m)		100-200 feet (30-60 m)	
	in.	(mm)	in.	(mm)	in.	(mm)
250	1	(25)	1-1/4	(32)	1-1/4	(32)
400	1-1/4	(32)	1-1/2	(38)	1-1/2	(38)

Notes:

- *1. These numbers are for natural gas (0.65 Sp. Gr.) and are based on 1/2 inch (3.45 kPa) water column pressure drop. Check supply pressure with a manometer, and local code requirements for variations. **For LP gas, reduce pipe diameter by one size, but maintain a minimum 3/4" diameter.**
2. Check supply pressure and local code requirements before proceeding with work.
3. Pipe fittings must be considered when determining gas pipe sizing.

- Install a sediment trap (drip leg) ahead of the gas controls (see Figure 9). Fit the trap with a threaded cap which can be removed for cleaning.




Figure 9. Proper Design for a Sediment Trap/Drip Leg

5. Install a manual gas shutoff valve for service and safety. Do not use a restrictive gas cock. **DO NOT USE FLEXIBLE GAS PIPING**, it will restrict the gas flow to the heater.
6. Disconnect the heater and its individual shutoff valve from the gas supply system during pressure testing of the system at pressures higher than 1/2 pounds per square inch (psi) (3.45 kilopascals [kPa]). If the test pressure is equal to or less than 1/2 psi (3.45 kPa), close the manual shutoff valve on the heater during the piping pressure test.
7. If the gas supply pressure is less than required, check for undersized pipe between the meter and the heater, a restrictive fitting, or an undersized gas meter. Gas supply pressures to the heater are listed in Table 6.

Table 6. Gas Supply Pressure Requirements

Supply Pressure	Minimum	Maximum
Natural Gas	5.0 Inches WC (1.2 kPa)	10.5 Inches WC (2.6 kPa)
LP Gas	11.0 Inches WC (2.5 kPa)	14.0 Inches WC (3.5 kPa)
Manifold Pressure	Nominal	
Natural Gas	3.0 Inches WC (1.0 kPa)	
LP Gas	9.0 Inches WC (2.2 kPa)	

NOTE: The maximum inlet gas pressure must not exceed the specified value. The minimum value listed is for the purpose of input adjustment. Refer to Table 6.

8. To connect the gas supply line to the heater's gas valve, make sure the steel elbow (supplied with the manifold) is screwed into the inlet side of the gas valve. The heater is designed so that the gas supply line may enter through either side of the heater. Hand tighten the elbow until the desired orientation is achieved.

⚠ CAUTION

Do not overtighten the elbow. Over tightening will crack the gas valve. Do not use teflon tape to wrap the elbow threads.

⚠ ATTENTION

Ne serrez pas trop le coude. Vous risqueriez de fissurer la soupape de gaz. N'entourez pas le filetage des coudes de ruban à joints.

9. Before operating the heater, test the complete gas supply system and all connections for leaks using a soap solution. Do not use an open flame.

⚠ CAUTION

Some leak test solutions (including soap and water) may cause corrosion or stress cracking. Rinse the piping with water after testing.

⚠ ATTENTION

Certaines solutions d'essai d'étanchéité (y compris l'eau et le savon) peuvent causer de la corrosion ou de la fissuration. Rincez les tuyaux à l'eau après l'essai d'étanchéité.

4.2 Manifold Pressure

Confirm that gas supply pressure is correct. If the gas supply pressure is less than required, check for undersized pipe between the meter and the heater, a restrictive fitting, or an undersized gas meter. Gas supply pressures to the heater, when it is operating, are listed in Table 6.

⚠ CAUTION

Manifold gas pressure for the LX and LT Low NOx natural gas heaters should be set at **3" WC**. Propane heaters should be set to **9" WC**.

⚠ ATTENTION

La pression du collecteur de pression pour les systèmes de chauffage au gaz naturel devrait être de **3" WC**. Pour les systèmes de chauffage au gaz propane devrait être de **9" WC**.

The manifold pressure may be checked by connecting a manometer to the pressure port on the outlet side of the valve. The pressure will be zero when the heater is not running. When the heater is operating the manifold gas pressure should be 3.0" WC for natural gas heaters and 9.0" WC for LP gas heaters. To adjust the manifold gas pressure, first remove the slotted cap next to the inlet pressure port on the inlet side of the gas valve. Under the slotted cap is a slotted plastic screw which increases the manifold pressure when turned clockwise and decreases the manifold pressure when turned counter-clockwise. After measurements, and adjustments if necessary, have been made, make sure to replace the 1/8" NPT gas valve plugs on the inlet and manifold pressure ports, and the cap on the manifold pressure adjustment screw. It is extremely important to replace these parts before leaving the installation. Failure to do so can result in damage to property or injury or death. *With the heater firing*, the pressure must be within the range shown in Table 6. Also check the pressure with the heater off.




Figure 10. Typical Piping Installation

4.3 Special Precautions for LP Gas

LP Gas is heavier than air and can therefore more readily collect or “pool” in enclosed areas if provision for proper ventilation is not made. Installation of pool heaters in enclosed areas such as pits is not recommended. However, if such an installation is required be sure to pay special attention to proper ventilation for LP gas. Locate heaters a safe distance from LP gas cylinders and filling equipment. Consult the National Fuel Gas Code (NFPA 54 / ANSI Z223.1, latest edition), the Natural Gas Installation Code in Canada (CAN/CSA B149.1, latest edition), and any other local codes and fire protection authorities about specific installation restrictions in your area.

SECTION 5. Water Connections

5.1 Water Piping

Figure 10 illustrates typical piping for pool equipment in pool/spa combination pools. With its electronic control, the LX and LT Low NOx heaters are particularly suited for this type of pool installation.

The heater must be protected from back-siphoning of water, which can result in dry starts. If there is any chance of back-siphoning, provide a check valve between the pool and the filter pump inlet.

Arrangement of pool system components other than as illustrated in these diagrams can affect the operation of the heater’s water pressure switch. Location of the heater above or below the pool water surface can also affect operation of the switch. In

general, the pressure switch can be adjusted to accommodate this effect if the heater water connections are no more than six feet below the pool water surface and no more than 15 feet above it. See instructions for pressure switch adjustment (Section 7.5) for more information about this.

Note that when pool equipment is located below the pool surface a leak can result in large scale water loss or flooding. Waterpik Technologies cannot be responsible for such water loss or flooding or the damage caused by either occurrence.

5.2 Check Valve Installation

Install a check valve in the plumbing between the pool inlet and the heater if there is any chance of back-siphoning.

Do not install any valve in the piping between the heater outlet and the pool, unless it is being used as a diverter valve. For special installations such as water connections below the water level of the pool, or for other questions contact the Technical Service department at (707) 776-8200 ext. 260.

5.3 Automatic Flow Control Valve

The inlet/outlet header of the LX and LT Low NOx heater comes equipped with an automatic flow control valve. The automatic flow control valve maintains the proper flow through the heater at rates up to approximately 125 Gallons Per Minute (GPM) (475 liters per minute [LPM]). If the filter system flow rate is higher than approximately 125 GPM (475 LPM), install a manual bypass valve (see Figure 9), then perform a temperature rise test (see Section 7.6) and adjust the flow using the bypass valve until the proper temperature rise is obtained.

5.4 Reversible Water Connections

The LX and LT Low NOx heaters are shipped with water connections on the right side, but they can be modified in the field to provide left-side water connections. This procedure involves removing the heat exchanger headers and reinstalling them on opposite ends of the tube assembly. Some of the heater wiring and control components must be relocated, so this procedure must be done only by a trained service technician.

Heat exchanger reversals are generally done before the installation of power and water to the heater. If you need to reverse the heat exchanger on a previously installed heater be sure that all electrical power, the gas supply and water supply have been turned off before starting the procedure. These instructions have been written to include the steps needed when reversing the water connections on an existing installation. If you are reversing the headers on a new installation, some steps will be ignored. Water connection reversal is illustrated in Figures 11 and 12. Proceed as follows:




Figure 11. Water Connections as Shipped




Figure 12. Water Connections Reversed

1. For an existing installation, drain the heater by removing the drain plug on the inlet/outlet header and the two drain plugs on the return header.
2. Remove the heater front panel (door).
3. Remove the two hex head screws that hold the raceway cover in place. They are located on the bottom flange of the raceway cover. Slide the raceway cover down to expose the raceway.
4. Remove the control panel assembly from the top panel (see figure 13 for panel identification). Lift the control panel cover. Remove the two philips head screws located at the front edge of the bezel. Lift the front of the bezel up until the entire assembly comes away from the top. Without removing any wires, slip the control assembly through the hole so that when the top is removed, the control assembly will stay with the heater.




Figure 13. LX/LT Panel Identification

5. Remove the four philips head screws that fasten the vent grill to the top. Remove the vent grill.
6. Remove the top. Remove the two hex head screws at the upper corners of the raceway. Now lift up on the front of the top and push it toward the rear of the heater. The top will slide off the heater.
7. Remove the water pressure switch's copper siphon loop tube from the header by first loosening the brass nut at the pressure fitting. Then carefully pull the tube out of the fitting. There should be about two inches of tubing inside the header. Be careful not to create any kinks in the tubing when handling it.

8. Clip the wire tie that bundles the wire harnesses leading from the control panel. Disconnect the two black temperature sensor wires from the back of the control panel. Coil the wires and place them on top of the flue collector.
9. Disconnect the high limit switch black wires from the wire harness leading to the control panel. There are quick disconnects at the end of the wires.
10. Remove the flat inlet/outlet header side cover plate located under the inlet/outlet header. There are four philips head screws, one in each corner, holding it in place.
11. Slide the upper right side panel up and out of the corner posts and place it aside.
12. For an existing installation, disconnect the gas supply pipe from the gas valve and remove it from the heater.
13. Remove the left side cover panel, held to the lower panel with two philips head screws at the corners.
14. Remove the flat return header side cover plate to expose the return header by removing the four philips head screws, one in each corner.
15. Slide the upper left side panel up and out of the corner posts and place it aside.
16. For an existing installation, remove the coupling nuts from the header and disconnect the water supply from the heater.
17. Remove the nine (9) bolts and washers from the inlet/outlet header and remove the header from the tube assembly.
18. Remove the nine (9) bolts and washers from the return header and remove the header from the tube assembly.
19. For an existing installation, inspect the header gaskets and clean the header's mating surface of any corrosion or debris. **Do not use any metal tools on the header surface.** Scratches may compromise the seal integrity.
20. Place the inlet/outlet header over the gasket on the left side of the tube assembly and align the holes in the header with the holes in the header bar.
21. Insert the nine (9) bolts with washers through the header and into the header bar. **Hand tighten the bolts.**
22. Place the return header over the gasket on the right side of the tube assembly and align the holes in the header with the holes in the header bar.
23. Insert the nine (9) bolts with washers through the header and into the header bar. **Hand tighten the bolts.**
24. Use a torque wrench to tighten the bolts on each header to eleven (11) foot-pounds. The bolts must be tightened in the sequence indicated in Figure 14.
25. After completing the entire sequence as indicated in step 24, repeat the tightening sequence torquing the bolts to eighteen (18) foot-pounds.

⚠ CAUTION

Failure to tighten the header as indicated in steps 24 and 25 may cause the header to leak or become permanently damaged from warping.

⚠ ATTENTION

Si le tuyau collecteur n'est pas serré conformément aux directives des étapes 24 et 25, il risque d'avoir des fuites ou de s'endommager de façon permanente.

26. Carefully bend the water pressure switch's copper siphon loop tube so that it reaches the inlet/outlet header now on the left side of the heater. **Do not** straighten out the coil directly behind the raceway and **do not** "kink" the tubing. Straightening the coil or kinking the tubing may result in poor heater operation. Insert the end of the tube into the fitting on the header. Tighten the nut onto the fitting one half turn past hand tight.




Figure 14. Header bolt tightening sequence

27. Route the wires that attach to the high limit switches along the copper siphon loop, back to the right side of the heater. Reconnect the wires to the wire harness.
28. Route the wires that attach to the temperature sensor along the copper siphon loop, back to the right side of the heater. Reconnect the wires to the tabs on the back of the control panel (marked as J4-1 and J4-2).
29. Use plastic wire ties to refasten the temperature sensor and high limit switch wires to the copper siphon loop. Bundle the wires near the control panel and fasten them with a wire tie.

NOTE: Be sure that none of the wires are in contact with a sharp edge or a hot surface.

30. Slide the upper right side panel back into the corner posts on the right side of the heater. Push it down until the tabs on the panel lock into the top of the corner posts.
31. Install the flat return header side cover plate (removed from the left side of the heater) on the right side to cover the return header by replacing the four philips head screws, one in each corner.
32. Slide the upper left side panel back into the corner posts on the left side of the heater. Push it down until the tabs on the panel lock into the top of the corner posts.
33. Remove the button plug from the inlet/outlet side cover plate.
34. Reinstall the inlet/outlet header side cover plate located under the inlet/outlet header. It is held with four philips head screws, one in each corner.

NOTE: Only the small tab of the top groove will fit behind the upper panel.

35. Remove the button plug type washer from the left side cover panel. This panel will not be used in reassembling the heater after a heat exchanger reversal. However, the button plug washer will be needed. **Do not** replace the cover panel over the vent switch outlet. Doing so may cause the heater to malfunction.
36. The gas line may enter the heater from either the left side or the right side. Replace the button plug washer in the hole through which the gas line will enter the heater.
37. Use the button plug to cover the hole on the opposite side of the heater.

NOTE: Be sure that the white fiber gasket is positioned on the top flange of the exhaust vent.

38. Replace the top. While positioning the top, pull the control panel through the hole and place it on top of the panel. Be sure that the flange at the back of the top panel slides under the flange on the rear panel to hold the top securely. Fasten the top to the heater by replacing the two hex head screws at the upper corners of the raceway.
39. Position the vent grill over the exhaust vent. Replace the four philips head screws that fasten the vent grill to the top.
40. Reinstall the control panel assembly into the top panel. Slide the back of the bezel into place, then lower the front, aligning the holes in the bezel with the holes in clips on the tabs on the top panel. Replace the two philips head screws located at the front edge of the bezel.
41. Slide the raceway cover up to the top of the heater. Be careful not to pinch any wires. Replace the two screws on the bottom flange to hold the cover in place.
42. Replace the front panel (door).

5.5 Connections at Heater

The LX and LT Low NO_x heaters have a standard two (2) inch water header and coupling design. With this feature, only nominal two inch PVC or CPVC may be connected to the heater. However, by installing the appropriate pipe adapters and two short pieces of two inch plastic pipe (supplied by the installer), any size existing pipe may be fitted to the heater.

To connect a section of 2" PVC or CPVC pipe to the heater, first slip a coupling nut onto the pipe. Then prepare the end of the pipe with the proper PVC/CPVC primer and glue. Follow the manufacturer's instructions provided with the primer and glue for preparation procedures and curing times. Apply the slip-fit side of the coupling to the end of the pipe. Allow the glue to cure completely. Set the o-ring into the groove on the face of the coupling. Slide the coupling nut up to the coupling and tighten it to the threaded connection on the header (see Figure 15).




Figure 15. Piping to Heater

5.6 Pressure Relief Valve

A pressure relief valve (PRV) is recommended in all installations, and is mandatory in any installation in which the water flow can be shut off between the heater outlet and the pool/spa.

A pressure relief valve is not supplied with the LX and LT Low NOx heaters. However, it is recommended that a pressure relief valve be installed and may even be required by local codes. Be sure to check any applicable installation codes in your area to determine whether a pressure relief valve is required.

The pressure rating of the valve should be at or below the lowest working pressure of any component in the system. Any pressure relief valve installed must comply with provisions of the standard described in ANSI Z21.22 for the United States of CSA 4.4 in Canada.

Follow these steps to install a pressure relief valve.

1. To protect the threads while drilling, screw the brass adapter (included with the Jandy PRV kit) into the blind threaded hole on the top of the inlet/outlet header.
2. Using the countersink in the center of the blind hole as a guide, drill a 1/4 inch hole through the plastic (see Figure 16).
3. Open the hole by reaming it with a 3/8 inch drill bit.
4. Open the hole again by reaming it with a 1/2 inch drill bit.

⚠ CAUTION

Initially drilling a 1/2" hole without reaming may cause the bit to "grab" on the plastic. This may cause personal injury or damage the plastic header.

⚠ ATTENTION

Si vous commencez à percer le trou de 1/2" sans alésage préalable, la mèche risque de « mordre » dans le plastique. Vous risquez de vous blesser ou d'endommager le tuyau collecteur de plastique.

5. Remove the brass adapter and clean the cuttings out of the hole.
6. Install the rubber washer at the bottom of the hole (see Figure 17).
7. Thread the adapter into the hole and tighten so that it seals against the rubber washer.
8. With a permanent marker, place a mark on the adapter so that the mark faces the same direction as the water connections on the header.
9. Remove the adapter from the hole.
10. Coat the threads of the pressure relief valve (PRV) with an appropriate metal to metal thread sealant.
11. Install the adapter on the PRV and tighten using two wrenches. Use the mark made earlier on the adapter to orient the PRV to the desired direction in relation to the water connections on the header.




Figure 16. Drill Hole for Pressure Relief Valve




Figure 17. Pressure Relief Valve Installation

12. Wrap the threads of the adapter with a suitable teflon thread tape.
13. Reinstall the adapter, with the PRV, into the plastic threaded hole and tighten it until the mark on the adapter is once again facing the same direction as the water connections on the header.

⚠ CAUTION

Do not use any pipe compound or pipe dope on the threads of the adapter or any part that comes in contact with the plastic headers. These compounds may damage the header over a period of time.

⚠ ATTENTION

N'utilisez ni pâte à joint ni pâte lubrifiante sur le filetage du raccord intermédiaire ou sur toute pièce qui entre en contact avec le tuyau collecteur. Ces produits risquent d'endommager le tuyau après un certain temps.

DO NOT TIGHTEN WITH A WRENCH.

Overtightening may crack the header. Route the discharge piping so that discharge from the pipe does not endanger anyone near the heater. Refer to your local installation codes for more detailed information. The valve setting should be at or below the maximum working pressure of any component in the filter system. The maximum working pressure of the LX and LT Low NOx heater is 75 psig.

5.7 Auxiliary Components, Chlorinators, Ozone Generators, and Sanitizing Chemicals

The LX and LT Low NOx heaters are manufactured with materials that are not compatible with high concentrations of ozone, chlorine, bromine, or other sanitizing chemicals. Heater damage caused by excessive chemicals or improper ozonization is not covered by the Waterpik Technologies warranty. Be sure to adhere to the following:

- When ozone is injected upstream of the heater, install an offgas mixing chamber, or an ozone bypass system between the heater and the ozone injector to prevent ozone and air from entering the heater.
- When chemical feeders are used, plumb the feeder downstream of the heater and install an in-line check valve between the heater and the feeder (a minimum of 18" is required between the heater and the check valve).

- Wire any electrical chemical feeder so that it cannot operate unless the filter pump is running. If the feeder has an independent clock control, synchronize it with the filter clock.
- Never deposit chemicals directly in the pool skimmer.

SECTION 6. Electrical

⚠ WARNING

ELECTRICAL SHOCK HAZARD. This heater contains wiring that carries high voltage. Contact with these wires may result in severe injury or death.

⚠ AVERTISSEMENT

POSSIBILITÉ DE CHOCS ÉLECTRIQUES. Ce système de chauffage contient du filage de haut voltage. Un contact avec ces fils peut résulter en des blessures sérieuses ou la mort.

⚠ CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.

⚠ ATTENTION

Au moment de l'entretien des commandes, étiquetez tous les fils avant de les débrancher. Des erreurs de câblage peuvent entraîner un fonctionnement inadéquat et dangereux.

6.1 General Information

Wiring connections must be made exactly as shown in the wiring diagram found on the inside of the heater door (see Figure 18). The heater must include a definite means of grounding. There is a bonding lug on the right side of the heater, where a bond wire must be attached.

6.2 Main Power

Electrical wiring must be in accordance with the latest edition of the National Electric Code (NEC), ANSI/National Fire Protection Association (NFPA) 70, unless local code requirements indicate otherwise.

The heater comes factory-wired intended for use with 230 Volt, 60 Hz AC field electrical supply. To use 115 Volt, 60 Hz AC requires changing the position of the voltage selector board on the power distribution board. This must be done by a certified electrician only, as with all wiring. Be sure that the power source to the heater is turned off or disconnected before servicing.

⚠ CAUTION

Do not provide power to the heater from the high voltage side of a time clock or pump relay. Doing so may cause damage to the heater or surrounding plumbing.

⚠ ATTENTION

N'installez pas l'alimentation électrique de l'appareil du côté haute tension d'un relais d'horodateur ou de pompe. Vous risquez d'endommager l'appareil de chauffage ou la tuyauterie qui l'entoure.




Figure 19. Field Wiring Connections

To wire the LX and LT Low NOx heater to a 115V or 230V /60 Hertz (Hz) electrical source:

1. Remove the door of the heater.
2. Remove the screws that hold the raceway cover and allow the cover to slide down.
3. Connect the wires from the power source to the leads on the right side of the heater in the space behind the raceway. You may need to remove the control to gain access to the leads (See Fig. 19).

NOTE: No external junction box is required.

6.2.1 Converting the Heater for a 115V Power Source

To convert the LX and LT Low NOx heaters to 115 Volt, 60 Hz AC requires reversal of the voltage selector board on the power distribution board. The following procedure should be performed **before** the heater is connected to a power source:




Figure 20. Location Of Power Distribution Board




Figure 21. Power Distribution Board With Voltage Selector Board Installed for 230 VAC

1. Identify the power distribution board on the heater. It is located to the left of the fan intake on the raceway (see Figure 20).
2. Cut the plastic wire tie that is holding the voltage selector board in place and discard the wire tie. Unplug the voltage selector board from the receptacle (see Figure 21).
3. Rotate the voltage selector board 180° and reinsert it into the receptacle so that the hole in the board is not visible. Be sure that the board is securely seated in the receptacle.

Note: The voltage selector board is keyed so that it will fit in only one direction for either selected voltage (either side of the board).

6.3 Bonding

⚠ CAUTION

This heater must be connected to a bonding grid with a solid copper wire not smaller in diameter than 8 awg.

⚠ ATTENTION

L'appareil de chauffage doit être connecté à une grille de mise à la terre par un fil de cuivre d'un diamètre de calibre minimal 8.

The National Electrical Code and most other codes require that all metallic components of a pool structure, including reinforcing steel, metal fittings and above ground equipment be bonded together with a solid copper conductor not smaller than a number 8 wire. The heater, along with pumps and other such equipment must be connected to this bonding grid. A special labeled bonding lug is provided on the right side of the heater to accommodate this requirement.

6.4 Auxiliary Time Clock Wiring

Electrical wiring must be in accordance with the latest edition of the National Eclectic Code (NEC), ANSI/National Fire Protection Association (NFPA) 70, unless local code requirements indicate otherwise.

If you install a time clock to control the filter pump operation, it is recommended that the time clock have its own low voltage (Fireman's) switch to turn off the heater before turning off the pump. The switch should shut off the heater about 15 minutes before the filter pump shuts off. This will allow for a more efficient operation by removing any residual heat contained in the heat exchanger back to the pool.

To install a time clock auxiliary switch into the heater circuit, follow these instructions (see Figure 22):

1. Remove heater door.
2. Remove the two screws securing the raceway cover. They are located on the bottom flange of the cover at the corners.




Figure 22. Remove Jumper from Terminal Block




Figure 23. Typical Time Clock Wiring

3. Slide the raceway cover down to expose the raceway.
4. Remove the factory installed jumper wire and tag from the terminal strip (see Figure 22).
5. Connect the low voltage wires from the time clock auxiliary switch to the two terminals. Use American Wire Gage (AWG) No. 14 gauge stranded copper wire with a temperature rating of 221°F (105°C) or greater (see Figure 23).

If your time clock simply interrupts the high voltage power supply or has a high voltage output, **do not connect the power supply of the heater to the output side of the clock**. Doing so will prevent the blower from purging the residual heat from the heater when the heater turns off. This situation will damage the heater. The blower must be allowed to run for 45 seconds after the heater shuts off.

6.5 Remote Operation

The LX Low NOx pool/spa heater controls can be wired for remote operation. All Jandy AquaLink RS Control Systems will permit the heater to be operated by remote control. If you are setting up a new pool or spa system, call your local Jandy distributor or the Customer Service Department for information on the correct RS Control System to meet your needs.

To maintain full functionality of an existing RS Control System when connecting to an LX Low NOx heater, first determine the revision level the programmed chip in the RS Control System's Power Center Board. To check the revision level of the chip, press and hold the reset button on the side of the indoor control panel for 10 seconds then release it. A number will appear on the display for approximately 5 seconds. This first number can be ignored. After the first number disappears, a second number will appear in the display window. It will consist of 4 digits followed by a revision level ("#### REV _"). If the revision level displayed here is at "I" or higher it will accommodate an LX Low NOx heater without any modification. If the chip is at a revision "H" or lower the chip will have to be replaced with a newer version, or to install the control without modification see information later in this section. An alternate method for determining the revision level of the programmed chip in your RS control, is described in steps 1-4 below. An updated chip can be obtained through Jandy by ordering the PPD Kit. Instructions for changing the chip are in the kit.

Do not connect more than two wires to any of the terminals in the RS Control System when connecting peripheral devices. If connecting the LX Low NOx heater to the RS Control System creates this situation, then a Multiplexing PCB kit must be used. Call your distributor or Waterpik Technologies to order the kit.




Figure 24. Wiring an LX Low-NOx to a Jandy RS Remote

To connect the LX Low NOx to your RS control system, follow the steps listed below (See Fig. 24).

1. Turn off the power to both the heater and the RS control.
2. Open the RS Power Center enclosure and remove the front dead panel.

NOTE: Only a revision "I", or higher, program chip in the RS system will support the LX Low NOx heater interface.

3. Remove the two screws holding the bezel in place. Turn the bezel over to view the circuit board on the back.
4. Locate the programmed chip on the Power Center Board (the larger square chip in the lower right corner of the circuit board). In the center of the chip is the revision letter. If the revision letter is "I" or higher go to step 5. If the revision level is "H" or lower, replace the chip. Directions for removal and installation of the chip are provided in the new PPD Kit .

NOTE: If ordering a new programmed chip, be sure to order the part number printed on the chip currently in your RS control.

5. Use 22 gauge 4-conductor wire (Jandy part # 4278) to run between the heater and the RS control, and match the wire color order.
6. The wires coming from the LX Low NOx heater can be "doubled up" on the red terminal bar with the four wires coming from the indoor controller.

NOTE: If you need to install more than two wires in each terminal, order a Jandy Multiplex PCB Kit, which includes the Multiplex Board (Jandy part # 6584). Never put more than two wires into each of the pins of the terminal bar.

7. On the heater's electronic control board, verify that the water temperature sensor is connected (J4-1 & J4-2), and that jumper is in place on W0.
8. Check all wiring, then apply power to both the heater and the RS control system. Operation can be verified in either Service or Auto mode. See your RS Control System manual for instructions about operation.

When the LX Low NOx heater is first powered, the display on the control will show "RS ONLINE". If there is an RS control connected to the heater, it will sense the RS unit and remain online. If an RS system is not connected to the LX Low NOx heater via the four conductor line, the message "RS ONLINE" will disappear after 15 seconds. When the display shows "RS ONLINE" all functionality of the control on the heater is disabled. The heater functions can be controlled only at the RS unit. However, sensor data is displayed at both the heater and the RS unit.

To temporarily use the heater controls, use the selector button to turn the heater from either "Pool" or "Spa" to "Off". The "RS ONLINE" indicator will disappear from the heater display. All functionality has now been returned to the control on the heater. In this mode the RS unit is no longer controlling the heater. To return the functionality to the RS unit, use a thin object, such as a paper clip or tooth pick, to depress the button marked "RS SERVICE".

An interrupt (on/off) type remote can be connected by removing the jumper wire on the terminal block located in the control compartment (see Figure 21) and connecting the two wires from the remote to the two terminals on the terminal block. This type of remote control will turn the heater on or off, but will not perform any other function.

This type of connection may be used to connect a Jandy AquaLink RS Control System utilizing **any** revision level programmed control chip. The control will automatically turn the heater on and off and will display the pool water temperature, but all other functionality and display information will be inactive. When using this type of connection, remember to set the LX heater's control to either "Pool" or "Spa" and set the corresponding thermostat control to maximum.

Consult with our Service Department for questions about installing remote controls manufactured by companies other than Jandy.

SECTION 7.

Operating Instructions

7.1 Normal Operation

The LX and LT-Low-NOx heaters are capable of automatic operation based on a call for heat at preset temperatures and an operator selection between pool or spa settings. Additionally, the heater may be controlled by a remote unit to anticipate bather load, changes in temperature settings, or a variety of other demands that might be encountered. The heater has an internal safety system which allows operation in a variety of conditions and prevents operation when certain adverse conditions are encountered. The heater is capable of diagnosing problems within the safety controls scheme, enabling faster service and less down time in the event of a failure.

When the heater is powered, water is flowing through the heater, and the temperature of the water entering the heater is below the temperature control setting, an operating cycle is initiated by the automatic control. The combustion blower is started and operates at high (normal) speed. If the blower pressure switch senses adequate airflow, the ignition sequence starts. First, a fifteen second pre-purge takes place. Next, the blower speed is reduced and the igniter is energized. After forty seconds of igniter heat-up time the gas valve is opened (approximately one minute after the call for heat). If flame is sensed at the burner within seven seconds, operation continues and the blower resumes high (normal) speed. Operation will continue until the temperature of the water entering the heater reaches the temperature control setting.

If ignition is unsuccessful, or if the flame fails during normal operation, the ignition control shuts off the gas valve. It imposes a post purge, initiates additional ignition cycles, and shuts down the system if ignition is not achieved in three cycles.

To reset the model LX Low NOx for another three cycles, press and release the mode button until the indicator on the LCD screen aligns with "OFF". Now press and release the button again until the indicator on the LCD screen aligns with the desired setting, either "POOL" or "SPA".

To reset the model LT Low NOx, press and release the mode button until the indicator lights for the "SPA" and "POOL" settings are off. Then press and release it again until the indicator light for the desired setting is back on.

7.2 Start-Up

WARNING

For your safety, when starting the heater, keep your head and face well away from the burner area to prevent any risk of personal injury.

AVERTISSEMENT

Pour votre sécurité personnelle lorsque vous mettez l'appareil en marche, tenez votre tête et votre visage loin du brûleur pour éviter tout risque de blessure.

WARNING

Vent pipes, and heater tops get hot! These surfaces can cause serious burns. Do not touch these surfaces while the heater is in operation.

AVERTISSEMENT

Les tuyaux d'aération et le dessus de l'appareil deviennent chauds! Ils peuvent causer de graves brûlures. Ne touchez pas à ces surfaces lorsque l'appareil est en marche.

CAUTION

Do not use this heater if any part has been under water. Immediately call a qualified service technician to inspect the heater and replace any part of the control system and any gas control which has been under water.

ATTENTION

N'utilisez pas cet appareil s'il a été plongé dans l'eau, même partiellement. Faites inspecter l'appareil par un technicien qualifié et remplacez toute partie du système de contrôle et toute commande qui ont été plongés dans l'eau.

CAUTION

Should overheating occur or the gas supply fail to shut off, turn off the manual gas control valve to the heater.

ATTENTION

En cas de surchauffe ou si l'alimentation en gaz ne s'arrête pas, fermez manuellement le robinet d'arrêt de l'admission de gaz.

CAUTION

Do not attempt repairs on the gas controls or appliance. Tampering is dangerous and voids all warranties.

ATTENTION

Ne tentez pas d'effectuer des réparations au système de régulation du débit du gaz ou à l'appareil. Toute modification non autorisée est dangereuse et entraîne l'annulation de toutes les garanties.

⚠ CAUTION

Keep all objects off the top of the heater. Blocking air flow could damage the heater, and may void the warranty.

⚠ ATTENTION

Ne posez aucun objet sur le dessus de l'appareil. Il pourrait empêcher la circulation de l'air, ce qui risquerait d'endommager l'appareil et d'annuler la garantie.

Be sure that there is water in the pool and that the surface level is above the skimmer or other inlet of the pool's filter system.

Confirm that pool water is flowing normally through the pool system and equipment. With any new pool or spa installation, operate the filter pump with the heater off long enough to completely clean the water. This will remove any installation residue from the water. Clean the filter at the end of this operation before starting the heater. Start the heater in accordance with the Operating Instructions section of this manual, with particular attention to the lighting and shutdown instructions and temperature control operation.

The heater may not start on the first try. Air in the gas line or other start-up situations may cause it to cycle. It will lock out if ignition is not achieved in three attempts (see Section 9.2, "Service Codes"). To provide three additional attempts, use the mode button and follow instructions in section 7.1 to reset the controller.

When the heater starts, immediately feel the outlet header of the heater to confirm that there is adequate water flow. The header should not be hot. Normally, water temperature will rise only a few degrees as it passes through the heater, and a "hot" header or pipe indicates low water flow.

⚠ WARNING

When the heater is fired for the first time, the combustion chamber refractory binder material is driven out by the heat of the flame. White smoke and/or sharp odors may be emitted from the vent during this period. Do not inhale combustion product fumes at any time, and especially when these fumes are being emitted. This "burn-in" period will last only a few minutes.

⚠ AVERTISSEMENT

Lorsque l'appareil est mis en marche pour la première fois, le matériau liant réfractaire de la chambre de combustion est expulsé par la chaleur de la flamme. De la fumée blanche et de fortes odeurs peuvent se dégager du tuyau d'aération à ce moment-là. N'inhaliez les fumées de combustion à aucun moment, surtout au moment où elles sont émises. Cette période de combustion ne durera que quelques minutes.

When raising the temperature of a cold pool, program the time clock to turn the pump off 23 hours after the start time (e.g., If the start time is 2:00 PM, then set the stop time at 1:00 PM.). This lets the filter system and heater operate continuously until the water reaches the temperature setting on the temperature control. When that happens, the heater will automatically shut off, but the filter pump will keep running.

7.3 Temperature Controls

The LX and LT Low NOx heaters have temperature controls that can be set to heat the pool and spa with independent temperature settings. The controls display information to indicate that the heater needs service, and diagnostic information for the service person (see Figure 25). The LX utilizes a liquid crystal display (LCD) screen to display the information while the LT uses indicator lights. The LX Temperature Control also displays pool/spa water temperature and allows for precise temperature settings of the heater.

The controls allow the heater to directly interface with all Jandy remote control units. The LX offers full remote control capabilities while the LT controls offer limited remote control.

Important: The temperature controls cannot be calibrated in the field. If the control is faulty, shut down the heater by following the procedures in Section 7.4 and have a qualified service technician replace the control. DO NOT use the thermostat switch to completely shut down the heater.

7.3.1 Information Displayed

The **Model LX** displays information on a **Liquid Crystal Display (LCD)** screen. The temperature control displays the water temperature of the pool or spa as well as the desired temperature (thermostat setting) in either Fahrenheit or Celsius. When there is water flowing through the heater (the filter pump is on), the water temperature is displayed in the right-most of two bar graphs in the center of the screen. This bar graph is labeled as 'Water Temp'. The selected thermostatic setting (either Pool or Spa) is displayed as a bar graph directly to the left of the water temperature bar graph. This bar graph is labeled as 'Thermostat Setting'. Note that when neither thermostat is selected (the heater is in off mode) only the water temperature is displayed.


If there is no water flowing through the heater (the filter pump is off), then only the thermostat setting for the mode selected, pool, or spa, will be displayed.

The **Model LT** heater does not display water temperatures or thermostatic settings.


When the heater is unable to operate due to a problem, the temperature control will identify which limit is not satisfied. The **Model LX** displays this information on the left side of the LCD under the LX logo. When the gas heater is firing, the LCD displays

'Heating' under the LX logo toward the center of the upper portion of the screen.

The **Model LT** displays this information by lighting a set of indicator lights located on the front of the control panel.



a) The LX Control Panel Display



b) The LT Control Panel Display

Figure 25. Temperature Control Panel

On the upper right-hand portion of the LCD screen on the **Model LX** is a selector arrow. Directly to the left of the selector arrow are three positions. They are 'POOL', 'OFF', and 'SPA'. This part of the display indicates the mode of operation in which the heater is set.

The mode of operation of the **Model LT** is shown by two indicator lights labeled "SPA" and "POOL"

Underneath the mode selector on the **Model LX** display screen is a Backlight indicator. To turn the backlight on, press the middle button to the right of the screen, labeled "Backlight".

Below the Backlight indicator is an RS service indicator, which displays "RS Online" when the heater is connected to an RS unit.

Directly below the RS Service indicator on the bottom right hand portion of the LCD screen is the Fahrenheit/Celsius temperature unit indicator.

The **Model LT** does not offer these features.

7.3.2 Turning the Heater On or Off

When power is supplied to the **Model LX** heater, the control goes into a diagnostic mode for approximately 15 seconds before the heater can be turned to the Pool or Spa mode. During this time the display will show "RS Online". If there is an RS control connected to the heater, it will sense the RS unit and remain online. If the control is not connected to an RS unit the "RS Online" indication on the display will disappear after the initial 15 seconds. When the display shows "RS Online" all functionality of the control at the heater is disabled. The heater functions can be controlled only at the RS unit. However, sensor data is displayed at both the heater and the RS unit. (See Section 6.5 "Remote Operation").

When power is first supplied to the **Model LT** heater, it also runs through a circuit board diagnosis to make sure that the control is working correctly. Indicator lights will flash during the 10 second diagnostic sequence.

After the initial diagnostic sequence on the **Model LX**, the heater can be turned to Pool or Spa mode by pressing and releasing the top (mode) button to the right of the LCD screen so that the selector arrow is aligned with either the Pool or Spa setting as seen on the LCD screen.

To turn the **Model LT** heater on, press and release the button located between the "POOL" and "SPA" indicator lights. Repeat pressing the button to achieve the desired mode of operation shown by the indicator lights. When neither light is on, the heater is "OFF"

It is now necessary to set the thermostat to the desired pool or spa setting.

7.3.3 Setting Pool and Spa Temperatures, Changing from Fahrenheit to Celsius

The **Model LX** heater displays temperature in Fahrenheit units when powered-up. To switch to Celsius, first turn the heater to the "Off" mode, then press the 'F°/C°' button. Once the desired temperature units are selected, the thermostat can be set. The left-most button below the LCD screen, labelled "Select", will select either the Pool or the Spa thermostat when depressed. Either "Pool" or "Spa" will be displayed in the bottom left corner of the LCD screen. The 'up' and 'down' buttons will increase or decrease the thermostat setting.

The **Model LT** heater control is less quantitative and less automatic. The pool or spa water temperature will need to be monitored manually when the control is adjusted. Temperature adjustments are made by turning the knob associated with the mode labeled below it. Turning the knob clockwise will increase the temperature setting. Turning it counterclockwise will decrease the setting. Once the desired setting is achieved, set the temperature lock by loosening the screw located at the bottom of the knob and rotating the dial stop counterclockwise until it contacts the knob. Tighten the screw to lock the stop in place.

When the thermostat setting exceeds the temperature of the pool or spa, the heater will fire. The heater will fire continuously until the pool or spa water is heated to the selected thermostat temperature. The control will not allow the heater to fire again for five minutes even if there is a call for heat, unless the thermostat setting is increased. In this case, the heater will fire within two minutes. This is to prevent short-cycling, and thereby increase the life of the heater.

When the **Model LX** heater is firing, "Heating" will be displayed underneath the LX logo. Note that in both the "POOL" and "SPA" thermostat settings, the temperature cannot be raised above 104°F (40°C).

Note that if power is momentarily lost, the thermostat settings will remain the same.

Also note that the heater should not be used to maintain water temperatures at or below 70°F (21°C). This will damage the heater.

7.4 Lighting and Shutdown Procedures

⚠ WARNING

Do not attempt to light the heater with the door off. Doing so may cause severe bodily injury.

⚠ AVERTISSEMENT

Ne tentez pas d'allumer l'appareil sans que la porte soit en place. Vous pourriez être victime de blessures corporelles graves.

Before starting your heater, be sure that all of the functions and limits of the LX and LT controllers have been set according to the previous section of this manual (Section 7.3). Once the controls are set to your preferences, follow the instructions outlined below. Read and follow all safety instructions first. A more detailed set of lighting and shutdown instructions are listed on the label located on the inside of the heater door and in Figure 26.

7.4.1 Lighting the Heater

Lighting instructions are as follows:

1. Turn off all electrical power to the heater at the main junction box.
2. Remove the heater door and turn the heater gas valve to off.
3. Wait 5 minutes before trying to start the heater.
4. Turn the gas valve control knob counterclockwise to ON (see Figure 27.)
5. Replace the heater door.
6. Turn on electrical power to the heater.
7. Turn on the filter pump.
8. Set the heater controls to the "SPA" position (mode). If the temperature of the water exceeds the thermostat setting it is necessary to increase the thermostat setting to exceed the water temperature. Adjust the thermostat setting (desired temperature) to be greater than the water temperature. The igniter lights the burner when the thermostat calls for heat.
9. Set the time clock, if one is installed.

7.4.2 Shutdown

Complete shutdown instructions are as follows:

1. Set both temperature controls to their lowest setting.
2. Press and release the mode button until the indicators show that the heater is off.
3. Turn off all electrical power to the heater at the junction box.
4. Open the heater door and turn the gas valve knob clockwise to off.
5. Shut off the external gas supply valve to the heater.


FOR YOUR SAFETY READ BEFORE OPERATING

⚠ WARNING: If you do not follow these instructions exactly, a fire or explosion may result, causing property damage, personal injury or loss of life.

- A. This appliance does not have a pilot light. It is equipped with an ignition device which automatically lights the heater. Do NOT try to light the burners by hand.
- B. BEFORE OPERATING, smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.
- WHAT TO DO IF YOU SMELL GAS**
- Do not try to light any appliance
 - Do not touch any electric switch; do not use any phone in your building.
 - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.
- C. Use only your hand to push in or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, don't try to repair it, call a qualified service technician. Force or attempted repair may result in a fire or explosion.
- D. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.

OPERATING INSTRUCTIONS

1. STOP! Read the safety information above on this label.
2. Set the thermostat to lowest setting and turn appliance switch to "OFF".
3. Turn off all electric power to the appliance.
4. This appliance is equipped with an ignition device which automatically lights the heater. Do not try to light the burners by hand.
5. Remove the heater door.
6. Turn gas control knob clockwise ↻ to "OFF".
7. Wait five (5) minutes to clear out any gas. Then smell for gas, including near the floor. If you smell gas, STOP! Follow "B" in the safety information above on this label. If you don't smell gas, go to next step.
8. Turn gas control knob counterclockwise ↶ to "ON".
9. Replace control access panel.
10. Turn on all electric power to appliance.
11. Set thermostat to desired setting and switch appliance from "OFF" to either "POOL" or "SPA".
12. If the appliance will not operate, check that the filter pump is on, the filter is clean and water is flowing to the pool. Otherwise, follow the instructions "To Turn Off Gas To Appliance" and call your service technician or gas supplier.



TO TURN OFF GAS TO APPLIANCE

1. Set the thermostat to lowest setting and switch appliance to "OFF".
2. Turn off all electric power to the appliance if service is to be performed.
3. Turn gas control knob clockwise ↻ to "OFF".
4. Replace control access panel.

Figure 26. Lighting and Shutdown Instructions




Figure 27. Gas Valve

7.5 Adjusting the Water Pressure Switch

⚠ CAUTION

The water pressure switch should be adjusted to turn the heater off when the pump is off. Setting the switch to close at too low of a flow can damage the appliance. Adjust the switch to turn the heater off, not on.

⚠ ATTENTION

Le manocontact de pression d'eau doit être réglé de façon à ce que l'appareil cesse de fonctionner si la pompe s'arrête. Si le manocontact est réglé pour se fermer lorsque le débit d'eau est trop faible, l'appareil risque de s'endommager. Réglez le manocontact pour qu'il arrête l'appareil, et non pour qu'il le mette en marche.

The pressure switch is preset at the factory for activation at 2 psi (14 kPa). Adjust the pressure switch only if any part of the filter system piping is 3 feet (0.91 m) or more above the top of the heater jacket.

Do not adjust the pressure switch if the heater is installed more than 15 feet (4.57 m) below or 6 feet (1.83 m) above the pool surface. Consult your local Jandy representative for recommendations.

On some installations, the piping from the heater to the pool is very short. The back pressure could be too low to trigger the pressure switch. If this happens, it may be necessary to install a directional fitting or elbows where the return line enters the pool. This will increase back pressure enough for the heater to operate properly.

Make sure the pool filter is clean before making any pressure switch adjustment. A dirty filter will restrict the water flow and the pressure switch cannot be adjusted properly.

To adjust the pressure switch, proceed as follows (see Figure 28).

1. Set the heater control to the "OFF" position.
2. Start the filter pump and confirm by means of a voltmeter that the pressure switch closes (if the switch fails to close, replace it with a switch that has a lower minimum setting).
3. Set the heater control to either 'Pool' or 'Spa'. Heater should start.
4. Pry out the top rubber dirt plug on the pressure switch.
5. Use a 7/32 inch Allen wrench to turn the adjustment screw very slowly clockwise until the heater goes off.
6. Slowly turn the pressure switch adjustment screw **counterclockwise** one-quarter turn. The heater should come back on.
7. Check the adjustment by turning the filter pump OFF. The heater fan will continue to run but the burners should shut off immediately. If they do not, restart the filter pump and repeat Steps 6 and 7. Check the adjustment again.
8. Return the pool temperature control to the desired temperature.

It may be necessary to repeat these steps to get a proper setting. The switch must be set so that the heater will not fire unless the pump is running. If a proper setting cannot be reached, contact the factory service department.




Figure 28. Adjustment of Pressure Switch

7.6 Temperature Rise

The LX and LT Low NOx pool and spa heaters have an internal bypass which accommodates a wide range of water flow. The bypass is easily adjustable to change the temperature rise for optimum performance and length of heater life. The bypass assures constant heat exchanger flow even though flow through the filter system will vary depending on how dirty the filter is.

For most installations, an external bypass valve is not needed in the heater water piping. This is due to the large size of the heater's internal bypass valve. If the pump flow rate is known to significantly exceed 125 gpm (7.9 l/s), an external bypass may be needed to assure proper heater operation.

Water flow should be confirmed upon start-up of the heater and in most servicing situations. If the flow is not normal, corrections must be made to the pool system. Flow is evaluated by determining the water temperature rise through the heat exchanger.

Before checking the temperature rise, make sure that the pool filter is clean and that gas supply and manifold pressures are correct. If necessary, clean all components of the filter system. Temperature rise is measured in the outlet of the far-right tubes when facing the inlet/outlet water heater. To measure the temperature rise, turn off the filter pump and remove the plastic plug to the right of, and just below the level of the outlet water pipe. This is mounted flush with the heater jacket (See Figure 29). With the plug removed, install the special thread adapter and "Pete's" plug fitting and insert a pocket thermometer. A temperature rise measurement kit is available through your Jandy distributor. See Section 11 of this manual for the correct kit number.

The internal bypass can be adjusted by means of a screw on the right-hand side of the header. To adjust the temperature rise to within the ranges specified in Table 7, proceed as follows:

1. If the piping system has an external bypass valve, close it.
2. Set the heater's control panel to the "Off" position.
3. Start the filter pump.
4. After three minutes, note and record the thermometer reading. This is the pool water temperature.
5. Start the heater by setting the control panel to either "Pool" or "Spa". Allow the heater to operate for five minutes or more. Note and record the thermometer reading. Subtract pool water temperature from this reading. This difference is the temperature rise. Refer to Table 7. If your measured temperature rise is within the range designated for your heater, skip steps 6 through 8.




Figure 29. Temperature Rise Measurement

6. Locate the bypass adjustment screw on the right-hand side of the header (see Figure 29). Loosen the nut so that the screw can be adjusted. A slight water leak past the nut may be expected. Turn the screw counterclockwise to decrease the temperature rise, and clockwise to increase the temperature rise as needed to achieve the ranges in Table 7. After the adjustment, tighten the nut so that no leaks occur.
7. If the temperature rise is too low and cannot be raised by means of the adjustment screw, the flow is in excess of 125 GPM (7.9 l/s). An external bypass will need to be installed, or if one already exists, open the external bypass valve gradually until the temperature range in Table 7 is achieved.
8. If it was necessary to adjust the external bypass as outlined in step 7, scribe a line on the bypass shaft and case to mark the correct adjustment position. Wire or remove the valve handle to prevent tampering.

Table 7. Water Temperature Rise and Flow Rates
(Measured at Input/Output Header)

Model	Minimum Temp Rise, °F (C)	Maximum Temp Rise, °F (C)	Minimum System Flow GPM (l/s)
250-L	24 (13)	28 (16)	30 (1.9)
400-L	36 (20)	40 (22)	30 (1.9)

In a system without external bypass, it may be necessary to make changes. If temperature rise is too low, a manual bypass must be installed. If temperature rise is too high, there is inadequate flow, possibly requiring a change to the piping system or a larger pump. Before proceeding with either remedy, verify proper heater operation. Low gas input results in low temperature rise and vice-versa. A problem with the heater internal bypass assembly also affects measured temperature rise.

SECTION 8. Maintenance

8.1 Water Chemistry

The mineral content of swimming pool water increases daily due to natural evaporation and the addition of sanitizing chemicals. If the mineral concentration in the pool gets too high, the excess minerals will deposit on the walls of the pool, in the filter system, and in the heater tubes.

The proper chemical balance in spa water is more critical than in a swimming pool heater operation. Due to the spa's size, high water temperature and heavy usage, chemical values in a spa can vary greatly. This chemical imbalance can result in unsanitary water conditions, and affect the life of the heater.

Proper chemical balances are necessary for sanitary bathing conditions as well as ensuring your heater's long life. Kits are available from your local pool supply dealer for making the various test for mineral content. One of these kits will detect copper in the system. This is usually a warning that corrosion is taking place, possibly due to a low pH value combined with other chemistry problems. The condition can be corrected by changing the spa water and closely monitoring the pH factor and chemical properties of the water. Be sure to keep your chemical levels within the values indicated in Table 8. **Waterpik Technologies does not warrant heat exchangers damaged by corrosive chemical levels or excess dissolved solids in pool or spa water.**

For spas, it is also necessary to perform water changes in addition to chemical treatment. It is recommended to change the spa water every 60 days for light usage and every 30 days if usage is heavy.

Table 8. Chemical Concentration Levels*

Test	Recommended Level
Free Chlorine or	1.0 to 3.0 ppm (3.0 to 5.0 spa)
Bromine	2.0 to 4.0 ppm (3.0 to 5.0 spa)
pH	7.4 to 7.6
Total Alkalinity (TA)	80 to 120 ppm
Calcium Hardness (CH)	200 to 400 ppm
Cyanuric Acid	30 to 50 ppm
Total Dissolved Solids (TDS)	Less than 2000 ppm
Copper	0 ppm

* Concentration levels taken from "Basic Pool and Spa Technology" published by NSPI (National Spa and Pool Institute).

8.2 Seasonal Care

⚠ CAUTION

Do not operate this heater outdoors at temperatures below 20 degrees Fahrenheit (°F) (-7 degrees Celsius [°C]).

⚠ ATTENTION

Ne faites pas fonctionner cet appareil à l'extérieur à des températures inférieures à 20 degrés Fahrenheit (°F) (-7 degrés Celsius [°C]).

8.2.1 Spring and Fall Operation

During periods when the pool is only going to be used occasionally, set the pool and spa control temperatures to 70°F (21°C) on the LX or the lowest setting possible on the LT. See Section 7.3.3. This prevents the pool water from becoming chilled, and minimizes the time required to raise the pool water back up to the desired temperature.

If the heater is not going to be used for a long period of time, shut it down completely. Follow the instructions found on the inside of the heater, or Figure 26 on page 27 of this manual.

8.2.2 Winterizing

In areas where freezing temperatures occur in winter and the pool or spa will not be used, have your service technician perform the following steps:

1. Turn off the main gas supply to the heater, using the gas cock outside the heater jacket.
2. Remove heater door.
3. Shut down the heater following the shutdown instructions found on the inside of the heater or Figure 26 on page 27 of this manual.
4. Remove the drain plugs from both the inlet/outlet header and the return header (see Figure 30 and Sections 11.3 and 11.4, Exploded Views), and completely drain the heater before the first frost.
5. After all water has drained from the heater, check for mineral buildup in the openings.
6. Use compressed air to blow out any standing water remaining in the heat exchanger.
7. Inspect the gaskets on the drain plugs and reinstall plugs, but do not tighten.
8. Disconnect the pressure switch from the siphon loop (copper tubing) (see Figure 31).
9. Cover the vent grill so that snow will not accumulate in the combustion blower, where it may freeze.




Figure 30. Draining the Heater




Figure 31. Winterizing the Pressure Switch

8.2.3 Spring Start-up

To restart the heater in the Spring, have a qualified professional technician reassemble the heater as follows:

1. Fill the siphon loop with approximately 5cc of SAE 50, non-detergent oil. Attach the copper tubing to the pressure switch (see Figure 31).
2. Tighten the drain plug.
3. Uncover the vent grill.
4. Make sure that power is supplied to the pump. Turn on the filter pump and circulate water through the heater for 5 minutes. Check for leaks while circulating.
5. Turn on the main gas supply to the heater at the gas cock outside the heater jacket.
6. Turn on the heater following the lighting instructions found on the inside of the heater, or Figure 26 on page 27 of this manual.

8.3 Inspection and Service

The LX and LT Low NOx heaters are designed and constructed to provide long performance life when installed and operated properly under normal conditions. Periodic inspections, especially at spring start-up, are important to keep your heater running safely and efficiently through the years. Improper maintenance can result in conditions where nausea or asphyxiation from carbon monoxide or flue gases could cause severe injury, property damage or death.

⚠ WARNING

Improper installation or maintenance can cause nausea or asphyxiation from carbon monoxide in flue gases which could result in severe injury, or death.

⚠ AVERTISSEMENT

Une installation ou un entretien inadéquat peut causer la nausée ou l'asphyxie en raison du monoxyde de carbone présent dans les gaz de combustion et même entraîner des blessures graves ou la mort.

8.3.1 Owner Inspection

Waterpik Technologies recommends that you inspect the heater on a continual basis and especially after abnormal weather conditions. The following basic guidelines are suggested for your inspection:

1. Keep the top and surrounding area of the heater clear of all debris.
2. Keep the area around and beneath the heater clean and free of all combustible materials such as paper, leaves, etc.
3. Do not store or use gasoline or other flammable vapors, liquids or chemicals in the vicinity of this or any other appliance.

Ne pas entreposer ni utiliser d'essence ni d'autres vapeurs ou liquides inflammables à proximité de cet appareil ou de tout autre appareil.

4. Do not use this heater if any part has been under water. Immediately call a qualified service technician to inspect the heater and replace any part of the control system and any gas control which has been under water.

N'utilisez pas cet appareil s'il a été plongé dans l'eau, même partiellement. Faites inspecter l'appareil par un technicien qualifié et remplacez toute partie du système de contrôle et toute commande qui ont été plongés dans l'eau.

5. If the heater is equipped with a pressure relief valve, check for corrosion in and around the valve. Twice a year, with the filter pump on, lift the release lever on the top of the valve to make sure that water runs freely through it. If corrosion is found, replace the pressure relief valve. When replacing the valve, be sure that the pump is off. Install the valve so that the discharge is directed away from any area that may be damaged by water.
6. Be sure all combustion air and ventilation openings are not blocked. Check for spider webs and other debris inside the heater, in the vents on all sides of the heater jacket and in the exhaust outlet—especially after a long period of nonuse.

8.3.2 Professional Inspection

Inspections performed at least once a year by a qualified technician are required to maintain your heater's safe and efficient operation. The following basic safety checks must be performed.

1. Check for loose or broken wires and terminal connections.
2. Make sure that the pressure switch operates properly by shutting the filter pump off and on a few times. The burner should go off immediately after the pump stops. An ignition sequence should start shortly after the pump is turned back on.
3. Inspect the electrical controls, specifically the following:
 - a. High limit controls.
 - b. Water pressure switch.
 - c. Exhaust temperature limit switch.
 - d. Automatic gas valve.
 - e. Fusible link.
 - f. Temperature control.
 - g. Control circuit fuse.
 - h. Ignition control.
 - i. Air pressure switch.
4. Inspect the venting system for blockage, leakage, and corrosion.
5. Inspect the combustion blower for damage.
6. Check for spider webs or other obstructions in the main burner orifices – especially at Spring start-up. Clean with wire brush if necessary.
7. Conduct a normal operating cycle and observe that the sequence proceeds as intended.

⚠ CAUTION

For your safety, when starting the heater, keep your head and face away from the burner area opening to prevent any risk of personal injury.

⚠ ATTENTION

Pour votre sécurité personnelle, lorsque vous mettez l'appareil en marche, tenez votre tête et votre visage loin du brûleur pour éviter tout risque de blessure.

8. If the heater is equipped with a pressure relief valve, clean any accumulated corrosion and make sure that water runs freely.
9. Inspect the outside of the combustion chamber and burner for corrosion and indication of improper operation.
10. Perform a temperature rise test in accordance with Section 7.6.
11. Regularly inspect electrical controls for deterioration. Repair and replace as necessary.
12. Make a visual check of the main burner flame. The flame can be seen in a view port on the front panel of the combustion chamber. When the blower is on low speed, the flame should be light blue in color and short (see Figure 32). When the blower is at full (high) speed, the flame will spread out over the burners in a "flying" mode and will remain light blue in color (see Figure 33). If flame appearance is otherwise, adjustment is necessary as described in the following section.

NOTE: After installation and first start-up, check the heat exchanger for black carbon soot buildup after the following periods of operation: 24 hours, 7 days, 30 days, 90 days and once every 6 months thereafter.

NOTE: Keep this manual in a safe place for future reference by you and your professional technician when inspecting and servicing the heater.

SECTION 9. Troubleshooting

9.1 General Heater Troubleshooting

Table 10 lists some of the more common problems, causes and solutions encountered when running the heater. Most problems occur when the heater is being started for the first time after installation or at Spring start-up. Careful installation and maintenance will help ensure years of trouble free use from your LX or LT Low NOx heater.

Be aware that premix combustion systems of the type found in the LX and LT heaters have special characteristics that affect operation and troubleshooting. See Sections 10.2 and 10.3 for important information about the system.




Figure 32. Flame view at low blower speed




Figure 33. Flame view at high speed

In addition to the service codes shown in the previous section, the ignition controller in both the LX and LT Low NOx model heaters has an LED light that flashes to indicate various different faults. Table 9 lists the LED codes and the corresponding fault description:

Table 9. Ignition Control LED Fault Codes

LED Code	Fault Description
The LED light is on continuously.	Ignition Control Fault. Refer to qualified service personnel.
LED single flash.	Air flow fault.
LED double flash.	Flame exists when there is NO call for heat. Refer to qualified service personnel.
LED triple flash.	Ignition lockout (heater has cycled three (3) times and locked out after the third try).

9.2 Service Codes

The LX and LT Low NOx controllers monitor several functions of the heater. In the event of a malfunction, the LX controller will display a service code on the left side of the LCD screen under the LX logo (see Figure 34). The model LT displays this information by lighting a set of indicator lights located on the front of the control panel (see Figure 35). Table 11 lists the LX and LT Low NOx Heater Service Codes along with potential causes and remedies.

Note: When the service codes marked with an asterisk (*) are displayed, the controls are still operable and the heater will operate normally when the displayed condition is remedied. Fault codes without an asterisk (*) will shut down the heater and control panel, and a flashing "Service" icon will be displayed.

9.3 Ignition Control LED Service Codes




Figure 34. LX Control Panel




Figure 35. LT Control Panel

Table 10.

LX/LT TROUBLESHOOTING GUIDE

#	Symptom	Cause	Remedy
1.	Pump not operating	A. No power B. Pump defective C. Incorrectly wired D. Time clock settings not synchronized with actual time	A. Check circuit breakers and power source. B. Replace. C. Recheck wiring. D. Check time clock setting.
2.	Flashback on start-up	A. Wrong gas B. Burner damage	A. Make sure gas supply matches gas indicated on rating plate. B. Replace burner.
3.	Lazy flame with yellow tip	A. Wrong gas	A. Make sure gas supply matches gas indicated on rating plate.
4.	Flame lifts and goes out (Low flame current).	A. Lean fuel/air mixture— Low supply pressure B. Lean fuel/air mixture— Too much negative combustion chamber pressure (draft) C. Lean fuel/air mixture— Low gas heat content	A. Correct supply pressure to assure 3.0" W.C. (Nat.) or 9.0" WC (LP) manifold pressure when firing. B. Increase draft openings by sliding damper beneath burners (see Section 10.3). C. Increase draft openings by sliding damper beneath burners (see Section 10.3).
5.	Short "non-flying" flame (High flame current)	A. Rich fuel/air mixture— Hi manifold pressure B. Rich fuel/air mixture— Too little negative combustion chamber pressure (draft) C. Rich fuel/air mixture— High gas heat content	A. Correct manifold pressure to 3.0" WC (Natural) or 9.0" WC (LP) B1. Locate and correct combustion system sealing deficiencies (see Section 10.3). B2. Decrease draft openings by sliding damper beneath burners (see Section 10.3). C. Decrease draft openings by sliding damper beneath burners (see Section 10.3).
6.	Not enough heat	A. Inadequate gas supply B. Low manifold gas pressure C. Heater size inadequate D. Temperature rise set incorrectly	A. Gas meter too small. Gas line from meter to heater too small. B. Gas pressure on heater manifold, should be adjusted to 3.0" W.C. for natural gas, 9.0" WC for LP gas. C. Replace with heater of higher input. D. Adjust temperature rise according to Section 7.6 of this manual.
7.	Heater pounding or knocking.	A. Water flow through heater too low	A. Check temperature rise according to Section 7.6 of this manual. If temperature rise is too high, check pipe size, pump capacity. Look for obstruction or closed valve in system.
8.	Heater condensing	A. Low water temperature B. Heater plumbed backwards	A. Flue product moisture will condense at the start-up until the heater water temperature reaches the normal operating conditions. B. Correct Plumbing.
9.	Igniter lights but main burners will not come on	A. Gas valve not at "on" position B. Air in gas line C. Gas valve failed D. No power to gas valve E. Low gas pressure	A. Turn knob to "on" position. B. Cycle ignition sequence until air is out of the gas line. C. Replace gas valve. D. Check controls for proper operation. E. Check supply pressure and manifold pressure.

Table 11.

LX/LT HEATER SERVICE DIAGNOSTIC GUIDE

DISPLAY CODE	CAUSE	REMEDY
LOW PRESS * <i>(pressure switch)</i>	<ol style="list-style-type: none"> 1. Pump is not running. 2. Low pump pressure. 3. Device connected at "Fireman Switch" terminal block is open. 4. Pressure switch fault. 5. Failed fuse 	<ol style="list-style-type: none"> 1. This is a normal display when the pump is OFF. No Service Required. 2. Clean filter or clear blockage/check position of valves in plumbing system. 3. This is a normal display when a device connected to the "Fireman Switch" operates to open the safety circuit on the heater. 4. Adjust or replace pressure switch. Refer to qualified service personnel. 5. Check heater wiring for shorts, replace fuse.
HI LIM SW <i>(hi-limit switch)</i>	<ol style="list-style-type: none"> 1. Water temperature in heater exceeds the internal limit. 2. Limit switch fault. 	<ol style="list-style-type: none"> 1. Perform Temperature rise test. Identify and correct cause of overheating. Refer to qualified service personnel. 2. Identify and correct loose connections or replace switches. Refer to qualified service personnel.
EXT SW 1 <i>(extra switch 1)</i>	<ol style="list-style-type: none"> 1. Exhaust temp. limit switch tripped. (manual reset) 2. Exhaust temp. limit switch fault. 3. Fusible link fault 	<ol style="list-style-type: none"> 1. Verify proper fan operation. Check for restriction or blockage of flue. Reset switch after problem is corrected. 2. Identify and correct loose connections or replace switch. Refer to qualified service personnel. 3. Identify and correct loose connections or replace fusible link. Refer to qualified service personnel.
AIR FLO SW <i>(air flow switch)</i>	<ol style="list-style-type: none"> 1. Broken, split, pinched or disconnected fan/switch tubing. 2. Fan not operating. 3. Fan running slow or premature fan failure. 4. Air flow restricted at intake or discharge. 	<ol style="list-style-type: none"> 1. Check tubing and replace if necessary. 2. Correct fault or replace fan. Refer to qualified service personnel. 3. Verify proper wiring for 115VAC or 230VAC. Refer to qualified service personnel. 4. Check for proper clearances around heater and for adequate room ventilation if enclosed. Inspect for blockage or restriction at discharge or flue. Refer to qualified service personnel.
AGS <i>(automatic gas shut-down)</i>	<ol style="list-style-type: none"> 1. Oscillating pump pressure. 2. Low gas supply pressure. 3. No flame at burners. 	<ol style="list-style-type: none"> 1. Clean filter or identify and repair cause of pump oscillation. 2. Identify and repair incorrect supply pipe size or pipe line blockage. Refer to qualified service personnel. 3. Identify and correct loose wiring connections, or problems with igniter, flame sensor , gas valve, or ignition control. Refer to qualified service personnel.
EXT SW 2 <i>(extra switch 2)</i>	Not used in this model.	
TEMP SENSOR* <i>(temperature sensor)</i>	<ol style="list-style-type: none"> 1. Faulty wiring or connection 2. Failed Sensor 	<ol style="list-style-type: none"> 1. Inspect Sensor wiring. Ensure sensor is plugged into back of control panel. 2. Replace Temperature Sensor. Refer to qualified service personnel

* **NOTE:** When these messages are displayed, the Controls are still operable and the heater will operate normally when the displayed condition is remedied. Faults shown above without an asterisk (*) will shut down the Heater and Control Panel and a flashing "SERVICE" is displayed.

SECTION 10. Professional Maintenance and Service

⚠ WARNING

SERVICING SAFETY

Some of the servicing procedures for the LX and LT Low NOx heaters are hazardous because they involve fuel gas, electricity, moving parts and procedures which require testing or temporary bypass of safety controls. For this reason, the heater must be serviced only by a qualified professional service technician.

IMPROPER SERVICE HAZARD

The LX and LT Low NOx heaters incorporate unique design features. Incorrect service of this heater can result in personal injury or damage to property. To avoid such hazards, the heater must be serviced only by a qualified professional service technician.

⚠ AVERTISSEMENT

PRÉCAUTIONS LORS DES RÉPARATIONS ET DE L'ENTRETIEN

Certaines procédures d'entretien et de réparation des appareils de chauffage à faibles émissions NOx LX et LT présentent des dangers, car elles mettent en jeu des gaz combustibles, des composants électriques, des pièces mobiles et des procédures qui nécessitent des mises à l'essai ou la dérivation temporaire des commandes de sécurité. Pour cette raison, l'appareil de chauffage doit être entretenu et réparé uniquement par un technicien professionnel qualifié.

DANGERS D'UN ENTRETIEN INADÉQUAT

Les appareils de chauffage à faibles émissions NOx comportent des caractéristiques techniques uniques. Une réparation ou un entretien inadéquat peut entraîner des blessures corporelles ou des dommages à la propriété. Pour cette raison, l'appareil de chauffage doit être entretenu et réparé uniquement par un technicien professionnel qualifié.

10.1 General Information

A qualified professional technician must service the LX and LT Low NOx pool heaters using Jandy's service procedures. Before calling for service, however, the owner should check for obvious problems. The other components in the pool system, including pump, filters and strainers, water valves, gas supply, electrical power and time clocks, have an affect on heater operation.

Confirm that the heater control is set to either 'POOL' or 'SPA' and that the corresponding temperature limit is set high enough to make the heater operate. Make sure the pump is operating, that the filter and all baskets are clean, that there are no mis-positioned water valves, that the gas or electric power supplies are not shut off and that time clocks are properly adjusted. Also be sure that there is no blockage of the exhaust vent grill or rear louvers, which supply combustion air to the burners.

10.2 "Premix" Induced-Draft Combustion System

The LX and LT Low NOx pool and spa heaters have an induced-draft combustion system incorporating special burners and a combustion blower. The burners are of special design in which most of the combustion air passes through the burners, resulting in a "premix" process. When burning natural gas this process produces very low NOx emission. This system is illustrated in Figure 36.




Figure 36. Induced Draft Combustion System

The system operates with a balanced combination of natural and induced draft. Air and gas are pulled into the burner venturis where they are mixed and conveyed to the combustion chamber. The combustion process produces heat and creates a negative pressure or "draft" condition. A small amount of secondary air is pulled into the chamber through holes and openings provided for that purpose. Hot combustion products pass through a highly efficient heat exchanger, where water absorbs most of the heat. Cooler products continue on and are pulled into the combustion blower, which exhausts them and stabilizes system flow. Exhaust is directly to the outdoor air through a grill, or for indoor heaters, through vent piping.

10.3 Special Service Issues - Premix Combustion System

10.3.1 System Operation

Premix combustion systems are less tolerant of fuel and air imbalance than lesser technologies. Fuel gas properties, incorrect supply or manifold pressure or draft problems affect their operation and reliability. If fuel gas heat content is low, combustion is "lean" and tends to be unstable. Flames may lift off the burner, causing outage. If heat content is high, "rich" combustion results, with low, hot flames that can overheat the burners. Likewise, low gas supply or manifold pressure results in lean, unstable combustion and high manifold pressure results in a rich process and hot burners.

"Draft", the negative pressure in the combustion chamber pulls air through the burners and the "draft" holes beneath the burners. Air is also pulled in through various cracks or openings at the edges of the combustion chamber and burner assembly. It is important to control draft by assuring that fit and sealing remain in "factory" condition. Service operations involving burner, heat exchanger or flue collector removal must be conducted with this in mind.

10.3.2 Field Service and Adjustment

As with all gas-fired appliances, the first order of business is to verify correct gas type, supply pressure and manifold pressure, as specified on the heater rating plate and in other sections of this manual. If the fuel supply differs greatly from "average", it may be necessary to replace gas orifices. Contact the Jandy Technical Service Group at (707) 776-8200 for assistance in that situation.

The most effective and convenient procedure for evaluation of system operation is measurement of the "flame signal". It can be measured at the pin connections on the ignition control next to the red LED lamp. A two-pin wire harness, available from Jandy Technical support, and a microammeter with a zero to 10 microamp scale are ideal for reading the flame cur-

rent. If flame current is less than $0.7 \mu\text{amps}$ the ignition control shuts down the system. Normally the signal is five to seven μamps . Figure 37 illustrates flame signal measurement.




Figure 37. Measuring the Flame Current

To accommodate construction or field factors affecting draft, a slide damper is provided beneath the burner inlets. Figure 38 illustrates this damper in its factory-adjusted position for natural gas, which is half open. Propane units are shipped with the damper in the fully open position. If gas type and pressures are correct, the damper can be used to adjust the system. "Lean" flame-lifting conditions can be corrected by opening the damper. This makes combustion chamber pressure less negative. Likewise, "rich" hot flames can be corrected by further closing the damper.




Figure 38. Slide Damper Draft Adjustment

Before making a damper adjustment, run the heater for ten or fifteen minutes to assure steady operation and measure the flame signal. Adjust the damper to provide a signal of five to seven μ amps. A higher signal indicates a "low" flame that produces excessive NOx and may cause burner failure. A lower signal indicates a less stable flame that may lift and go out when the unit is cold.

10.4 Heater Components and Their Operation

1. **Gas Valve / Regulator** - The gas valve controls gas flow into the manifold. It provides flow only when the temperature control requires heat and only if all safety controls enable operation. It is also a positive pressure regulator. It regulates the gas pressure in the manifold to specifications addressed earlier in this manual. This is necessary for proper operation of the burner system.
2. **Temperature Control** - Both the LX and LT Low NOx heater models are equipped with an electronic control which senses water temperature by means of a thermistor and controls heater operation to bring the water to the temperature selected. It has an option for two separate thermostat settings which are typically used to set pool and spa temperatures.
3. **Ignition Control** - The ignition control provides energy for ignition of the air/gas mixture, monitors the flame and controls the gas valve. When the temperature control requires heat, the ignition control provides a pre-purge of the combustion chamber. Once the pre-purge is complete the ignition control lowers the blower speed and then applies electrical power to a "hot surface" igniter. When the igniter is hot enough, the ignition control opens the gas valve. It has sophisticated means to sense ignition and flame condition so that unburned gas will not escape. Once the ignition control has sensed flame, it de-energizes the igniter and returns the blower to full speed. After the burner is shut off, the ignition control continues blower operation to provide a post-purge period.
4. **Igniter** - The hot surface igniter is a crystalline element which becomes very hot when electrical power is applied to it. The hot surface igniter directly ignites the air/gas mixture in the combustion chamber.
5. **Limit Switches** - Two limit switches prevent excessive water temperature - one within the heat exchanger and one for water leaving the heater. If either senses excessive temperature, burner operation is interrupted.
6. **Water Pressure Switch** - This control senses whether or not water is available to the heater by measuring back pressure inside of the heat exchanger. If the pool water pump fails or the water filter is blocked, the pressure switch prevents operation of the burner.
7. **Fusible Link** - This is a single-use switch which detects abnormal temperature in the component compartment of the heater. It is a fusible link which is held to the combustion chamber just above the burner tray by a sheet metal bracket. Excessive temperature in the component compartment, possibly due to a burner flash-back will cause the link to fail. This opens the safety circuit which shuts off the gas valve and shuts the heater down.
8. **Air Pressure Switch** - This switch verifies that air is flowing through the combustion system by sensing pressure. It shuts off the heater if air flow is inadequate.
9. **Flame Sensor** - The flame sensor is the electrode through which the ignition control detects "rectification" of current passed through the flame. Inadequate rectification indicates an unsatisfactory flame condition. The rectification signal can be measured by attaching the leads of a DC ammeter to the two pins on the connector of the ignition control labeled "FC". A wire harness, available from Jandy, makes it easier to attach the voltmeter leads. The flame current should not be less than 1.5 micro-amps. If the flame signal is less than 1.5 micro-amps, you can adjust the throttle strip on the burner tray to allow more air into the combustion chamber. This can increase the flame signal.
10. **Exhaust Temperature Limit Switch** - A manually resettable limit switch prevents exhaust temperatures in excess of 240°F (116°C). If it senses excessive temperature the switch opens and burner operation is interrupted. Once the cause of the excessive exhaust temperature has been corrected, the switch may be reset and used again.

10.5 Electrical Troubleshooting

This section describes procedures for checking the electrical power and control components of the heater one at a time and in the order they appear in the control circuit. It is important to follow the sequence of this trouble shooting guide because the safety circuit is connected in series.

These procedures require a Volt-Ohm meter with a minimum 0-250VAC voltage range, and 1-1000 Ohm resistance range. Figure 39 shows the power and control circuits and where to take measurements. Location numbers in circles have been added, and will be referenced in the following sections.

Where test points are shown at circuit board connectors, the probe of the meter can be carefully pushed into the connector along side of the wire at the connection to be measured.

The electrical power supply can be checked with the heater not set to fire. All other procedures need to be checked with power correctly supplied to the heater, all external devices set so that the heater is allowed to fire and the heater's thermostat set so that there is a call for heat.

As stated at the beginning of the manual, some of these procedures are hazardous. Only a qualified service technician should service the heater.

10.5.1 Electrical Power Supply

The electrical components of the LX and LT Low NOx pool heaters are designed to operate with supply voltage ranging from 98V to 126V at 60 Hz if connected to a nominal 115 volt power supply, or 196V to 253V at 60 Hz if connected to a nominal 230 volt power supply. Measure supply voltage at the power supply leads where they enter the heater (identified as points A, B and C on the wiring diagram in Figure 39.). Use the voltages in Table 12 to verify that the correct voltage is supplied to the heater.

If no voltage is present, correct this external power supply problem to the heater. Circuit breakers, time clock settings or similar devices may be the problem. Voltage outside of the above ranges may be due to poor wiring, poor connections, other loads such as air conditioning compressors or to an electric utility company problem. Arrange for correction of the voltage as appropriate.

Table 12. Supply Voltage Measurements

MEASURE BETWEEN THESE POINTS	EXPECTED VOLTAGE WITH 230V SUPPLY	EXPECTED VOLTAGE WITH 115V SUPPLY
A and B	98 - 126 Volts	0
A and C	98 - 126 Volts	98 - 126 Volts
B and C	196 - 253 Volts	98 - 126 Volts
<ol style="list-style-type: none"> Point A is the ground connection on the heater. Point B is the location at which the red power lead enters the power circuit board. Point C is the location at which the black power lead enters the power circuit board. 		

When you are sure that the voltage supplied to the heater is correct, check the voltage being supplied to the transformer by the power supply circuit board. This can be done by measuring the voltage between the wires of the four-pin connector on the power supply circuit board. These points are designated as test points D, E, F, and G on Figure 39. The voltages measured between any two of these four points will be determined by the voltage supplied to the transformer (see Table 13 for expected voltages).

If the voltages measured do not fall within the limits shown in Table 13, then there is a problem with the power supply circuit board and the board must be replaced.

Table 13. Voltage Supplied To Transformer

MEASURE BETWEEN THESE POINTS	EXPECTED VOLTAGE WITH 230V SUPPLY	EXPECTED VOLTAGE WITH 115V SUPPLY
D and E	0	98 - 126 Volts
D and F	98 - 126 Volts	98 - 126 Volts
D and G	98 - 126 Volts	0
E and F	98 - 126 Volts	0
E and G	98 - 126 Volts	98 - 126 Volts
F and G	196 - 253 Volts	98 - 126 Volts
<ol style="list-style-type: none"> Point D is the location at which the white wire with the black trace enters the 4 pin connector. Point E is the location at which the white wire with the red trace enters the 4 pin connector. Point F is the location at which the red wire enters the 4 pin connector. Point G is the location at which the black wire enters the 4 pin connector. 		

10.5.2 Controller

The controller must be operational in order to check the control circuits of the heater.

10.5.3 Control Circuit Troubleshooting

The heater controls are arranged in several 24V 60Hz circuits with some operating and safety controls arranged in series circuits.

Troubleshooting is done by probing for voltage between the common and various points in the circuit to determine which component is preventing operation. Check points are indicated on Figure 39. The black lead of the meter should be attached to the common tap on the secondary side of the transformer and may be left there throughout most of the procedure.

The recommended procedure steps through each circuit in a sequential way, and each section assumes that components from all previous sections have been tested and are operational. However, verifying voltage at any of the numbered points in that circuit confirms that all prior components of the circuit are operational.

10.5.3.1 Transformer

Attach the black lead of the voltmeter to the terminal on the secondary side of transformer with a yellow wire attached to it (common). This is test point 1 on Figure 39. Touch the free lead of the voltmeter to the terminal on the secondary side of transformer with a red wire attached to it (24V tap), test point 2. The voltmeter should read between 20-28 Volts. Leave the black lead of the meter on the common tap (test point 1), and move the free lead of the voltmeter to the terminal on the secondary side of transformer with a white wire with yellow tracer attached to it (12V tap), test point 3. The meter should read 10-14 Volts. If the voltage at either of the test points does not fall within the limits mentioned above replace the transformer.

10.5.3.2 Fuse

Leave the black voltmeter lead in place at test point 1. Touch the free lead of the voltmeter to test point 4, which is on the back of the controller where the red wire from the transformer enters the end of the connector. You will need to push the voltmeter lead into the back of the connector along side of the wire pin. The meter should read 20-28 Volts. If there is no voltage, the fuse has failed. Inspect the rest of the wiring, especially the safety circuit, to be sure that there is no "short" such as contact of a terminal with the heater chassis or another terminal which may have caused the fuse to fail. Correct any such condition and replace the fuse. Use only a 2 amp, 1 1/4" long x 1/4" diameter, quick acting, glass tube type fuse. A 4 amp fuse is used when an EZ Switch Kit is installed.

10.5.3.3 Water Pressure Switch/External Interlocks or Fireman Switch Circuit

Start by checking the voltage at the two legs of this circuit at the back of the controller, (see test points 5 and 6 in Figure 39). Leaving the black lead of the meter on test point 1, check the voltage at test point 5, where the black wire from the pressure switch enters the ten-pin connector on the back of the controller. If there is not 20-28 Volts at this point, either the controller or the ten-pin wire harness is faulty and must be replaced. If 20-28 Volts is detected at test point 5, then move the red lead of the meter to test point 6 where the white wire from the fireman switch terminal block enters the ten-pin connector. If 20-28 Volts is detected at this point, the devices in this circuit are closed and the circuit is working properly.

If there is no voltage, either the pressure switch contacts or the contacts of the external switch (fireman switch) are open. To determine which device is causing the fault, move the red lead of the meter to the contact on the water pressure switch where the black wire is connected, (test point 7). Voltage to this point means that the wire harness between the controller

and the water pressure switch is good. If there is no voltage at test point 7, look for a loose connection or replace the ten-pin wire harness. If there is voltage at test point 7 then move the lead from test point 7 to the contact on the other side of the water pressure switch (test point 8). No voltage here means that the pressure switch contacts are open. This is almost always due to a water flow deficiency, the most common one being a blocked water filter or defective pump. However, sometimes it is due to blockage of the copper siphon loop tube or mis-adjustment of the switch. Investigate thoroughly, referring to Section 7.5 on "Adjustment of Pressure Switch". If there is no problem with the pool system or pressure switch adjustment, replace the pressure switch.

If test point 8 shows 20-28 Volts, check the voltage going to the external device. Move the lead of the meter to the lower right terminal screw on the fireman switch terminal block (test point 9). No voltage means that there is a bad connection in the wire between the water pressure switch and the terminal block. If 20-28 Volts is shown here, it ensures that the correct voltage is being supplied to the external switch. Now move the lead to the upper right terminal screw on the terminal block (test point 10). No voltage here means that the external device is not working properly. The time clock switch or other external interlock may be mis-adjusted, mis-connected or defective. Correct this external problem. If there is 20-28 Volts at test point 10 then there is a bad connection between the terminal block and the controller. Replace the ten-pin connector wire harness.

10.5.3.4 Temperature Limit Switches Circuit.

Since the limit switches are not easily accessible, you can check the voltage between test point 1 and the two legs of the circuit at the controller (see test points 11 and 12 in Figure 39).

Leaving the black lead of the meter on test point 1, check the voltage at test point 11, where the white wire from the 150° limit switch enters the ten-pin connector on the back of the controller. If there is not 20-28 Volts at this point, either the controller or the ten-pin wire harness is faulty and must be replaced. If 20-28 Volts is detected at this point, then move the red lead of the meter to test point 12 where the white wire from the 135° limit enters the ten-pin connector. If 20-28 Volts is detected at this point, the devices in this circuit are closed and the circuit is working properly.

If there is no voltage, one of the limit switches is open. This is normally due to excessive water temperature, which should be thoroughly investigated before replacement of limit switches. Excessive water temperature may be caused by low water flow. Water flow deficiency may be due to obvious problems such as a defective pump or blocked water filter. Alternatively, excessive water temperature may be due to

over-firing, or to a problem with the water piping or the heater's internal bypass control. Over-firing might be a result of an incorrect gas orifice or supply of propane gas to a heater intended for natural gas.

If there are no such fundamental problems, identify which of the switches is open. Limit switch access is through the limit switch covers on the side of the heater to which water pipes are connected. Remove the limit switch covers from the header and gently remove the switches from the wells.

Note that the limit switches have different trip points, and it is important that replacements are correct. The 150°F switch has a red dot on the top of the brass fitting, and must be installed in the lower (horizontal) well in the header. The 135°F switch has no dot and must be installed in the upper (vertical) well in the header.

Leave one meter lead in place at test point 1. Move the other meter lead to the terminal connection on the 150° switch (test point 13) that is connected back to the controller. The voltmeter should read 20-28 Volts. No voltage here means that the ten-pin wire harness is bad and should be replaced. If voltage is detected at this point move the lead to the other terminal of the switch (test point 14). If the voltmeter does not show voltage then the 150° limit is bad and should be replaced. If the meter reads 20-28 Volts, move the lead to the terminal of the 135° limit that is connected to the wire that jumps between the two limit switches (test point 15). No voltage here means that the wire assembly is bad and needs to be replaced. 20-28 Volts shows that the wire between the two limits is making a good connection. Now move the lead to the other connection terminal on the 135° limit (test point 16). No voltage at this point indicates that the limit switch has failed and needs to be replaced. Voltage here would show that the limit is good and that the ten-pin wire harness may have a bad connection. Replace the wire harness if necessary.

10.5.3.5 Fusible Link / Exhaust Temperature Limit Switch Circuit

Since the exhaust temperature limit switch is not easily accessible, you can check the voltage between test point 1 and the two legs of the circuit at the back of the controller (see test points 17 and 18 in Figure 39).

Leaving the black lead of the meter on test point 1, check the voltage at test point 17, where the white wire from the fusible link enters the ten-pin connector on the back of the controller. If there is not 20-28 Volts at this point, either the controller or the ten-pin wire harness is faulty and must be replaced. If 20-28 Volts is detected at this point, then move the red lead of the meter to test point 18 where the white wire from the manual reset high limit switch enters the ten-pin connector. If 20-28 Volts is detected at this point, the devices in this circuit are closed and the circuit is working properly.

If there is no voltage, either the fusible link or the contacts of the manual reset switch are open. To determine which device is causing the fault, check the fusible link first.

Leave one lead of the meter at test point 1. Move the other lead of the meter to the contact on the fusible link where the wire is connected back to the controller, (test point 19). Voltage to this point means that the wire harness between the controller and the water fusible link is good. If there is no voltage at test point 19, look for a loose connection or replace the ten-pin wire harness. If there is voltage at test point 19 then move the lead to the contact on the other side of the fusible link (test point 20). No voltage here means that the fusible link is open. This indicates higher than normal temperatures in the component compartment (vestibule). Normal component compartment temperature is well below 300°F. The fusible link is designed to fail at temperatures above 305°F. Excessive temperatures are almost always due to flashback conditions caused by a damaged burner, manifold pressure being set too high or incorrect gas supply type. Check to be sure that the type of gas being supplied to the heater matches the designation on the rating plate. Thoroughly inspect the burners and orifices for damage. Finally, check and adjust the manifold pressure if necessary. Replace the fusible link. If test point 20 shows 20-28 Volts, then the top of the heater must be removed to gain access to the manual reset exhaust limit switch.

To check the manual reset switch leave one lead of the meter at test point 1 and place the other lead on the contact of the manual reset switch (test point 21) that is connected to the wire leading to the fusible link. If test point 21 does not show 20-28 Volts, then the wire assembly between the fusible link and the manual reset switch must be replaced. If 20-28 Volts is detected, then move the lead to the other contact of the manual reset switch (test point 22). Voltage here means that the ten-pin connector wire harness is faulty and must be replaced. If no voltage is detected, the switch contacts have opened due to excessive exhaust temperatures. This condition is usually caused by a blocked exhaust vent. Be sure that the vent is clear of all debris, then push the red button on the switch to reset the circuit. If there is still no voltage detected, the manual reset switch must be replaced.

10.5.3.6 Blower Pressure Switch Circuit

The blower must be operating during the test procedure for the blower pressure switch. Start by checking the voltage between test point 1 and the two legs of this circuit at the back of the controller, (see test points 23 and 24 in Figure 39).

Leaving the black lead of the meter on test point 1, check the voltage at test point 23, where the purple wire from the blower pressure switch enters the ten-pin connector on the back of the controller. If there is

not 20-28 Volts at this point, either the controller or the ten-pin wire harness is faulty and must be replaced. If 20-28 Volts is detected at this point, then move the red lead of the meter to test point 24 where the black wire with a yellow trace from the blower pressure switch enters the ten-pin connector. If 20-28 Volts is detected at this point, the device in this circuit is closed and the circuit is working properly.

If there is no voltage, the pressure switch contacts are open. Leave one lead of the meter at test point 1. Move the other lead of the meter to the contact on the blower pressure switch (test point 25) where the purple wire is connected. Voltage to this point means that the wire harness between the controller and the blower pressure switch is good. If there is no voltage at test point 25, look for a loose connection or replace the ten-pin wire harness. If there is voltage at test point 25 then move the lead to the contact on the other side of the blower pressure switch (test point 26). No voltage here means that the pressure switch contacts are open. This is usually due to a blower speed problem or a problem with the air pressure tube connection between the blower housing and the switch.

Be sure that the blower is on and that it is working properly. Check that the gray flexible tube between the blower pressure switch and the blower housing is connected at both ends and has no holes or splits. Replace the tube if necessary. If there is no problem with the blower or the tube, replace the pressure switch.

If test point 26 shows 20-28 Volts, then there is a bad connection between the blower pressure switch and the controller. Replace the ten-pin connector wire harness.

10.5.3.7 Gas Valve Voltage

The gas valve will operate only when there is a call for heat and all safety circuits have been satisfied. If the gas valve does not operate under these conditions, check the voltage going to the gas valve. Place one voltmeter lead in the four-pin connector on the back of the controller where the yellow wire is connected (test point 27). Touch the free lead of the meter to the gas valve terminal where the brown wire is attached at the gas valve (test point 28). This test point will have voltage present only during a trial for ignition or during normal operation. The meter should read 20-28 Volts. If there is no voltage, then there is a bad connection between the gas valve and the controller. Replace the four-pin connector wire harness.

Listen closely to the gas valve when it is first energized (24V first appears at test point 28 during the trial for ignition). There should be an audible "click" when the valve opens.

If there is voltage at test point 28, but the gas valve does not open, replace the valve.

10.5.3.8 Igniter/Ignition Control Circuit

WARNING

The igniter, power supply circuit board and some terminals of the ignition control utilize 115V or 230V power and require appropriate servicing precautions. Note that wires and terminals of these components may be "hot" even when the component is not operating.

AVERTISSEMENT

Le dispositif d'allumage, le circuit d'alimentation électrique et certaines bornes de la commande d'allumage utilisent une tension de 120 V ou de 220 V et exigent des précautions appropriées lors du service d'entretien et de réparation. Notez que les fils et les bornes de ces composants peuvent être chauds même si le composant ne fonctionne pas.

With the igniter leads connected to the power supply board there will be voltage of 98-126 VAC between the quick disconnects at the ends of the igniter wires, test point H and test point I, if the heater is connected to a 115V supply. If the heater is connected to a 230V supply then the voltage reading between these two points will be 98-126 VAC if read with an RMS meter, or 50-65 VAC if read with a non RMS meter. This voltage will be applied only when there is an attempt to ignite the burner or when the ignition control's flame sensing system has determined that it is OK to allow burner operation. Even if voltage has been confirmed at the end of the safety circuit, the "trial for ignition" sequence is imposed by the ignition control. This sequence consists of a 15 second period of pre-purge, a 40 second period for heat-up of the igniter and a 7 second trial for ignition. During this last 47 seconds there is voltage between test point H and test point I. If satisfactory ignition is not achieved, the igniter is turned off and the system waits for a 15 second inter-purge period. The system may go through this cycle as many as three times, but thereafter it is "locked out" by the ignition control. Additional attempts will be made only if the call for heat is interrupted by turning off electrical power or setting the control to "Off" and then back to "Pool" or "Spa".

To trouble shoot the ignition control's igniter circuit, connect the voltmeter leads at test points H and I, and set the control to call for heat. Observe that the normal ignition sequence takes place. After the 15 second pre-purge, note the voltage between test points H and I. Then look for the glow of the igniter through the view port on the front of the combustion chamber. If the correct voltage is detected between points H and I during the trial for ignition but the igniter does not glow, check the connections to the igniter.


Check the igniter with the ohmmeter. Disconnect the igniter wires at the quick disconnects. Place one lead of the meter on each wire of the igniter. The resistance should read between 40 and 75 Ohms at ambient air temperature. If the meter reads outside of this range or shows an open or short circuit, replace the igniter.

If voltage does not appear between points H and I during the trial for ignition, there may be a bad connection or a short on the power distribution board or the ignition control. Check all connections on the power distribution board and the ignition control for loose or corroded connections before continuing with this checkout procedure.

If your heater is connected to a 230 VAC supply, perform the following procedure. If your heater is connected to a 115 VAC supply, skip to the paragraph indicated with bold type. Place the black lead of the meter in contact with the pin on the power distribution board that is labeled "ACH" (test point C). Place the red lead of the meter in contact with the pin on the power distribution board that is labeled "L1" where the black wire is connected (test point J). The meter should read 196-253 VAC. If the meter shows voltage outside of this range, the power distribution circuit board has a loose connection or has shorted. Check the connections or replace the board. If the meter shows voltage within the range above, then move the red lead to the "L1" connection on the ignition control (test point K). Incorrect voltage here means that the wire between the power distribution board and the "L1" connection on the ignition control is faulty. Check the connections or replace the power distribution board. Voltage at test point K shows that voltage is getting to the ignition control. Now move the red meter lead to the "IGN 240" connection on the ignition control (test point L). No voltage at this location during the trial for ignition means that the ignition control has failed and needs replacement. If the ignition control is working properly, it will have stepped the voltage down to 98-126 Volts RMS (50-65 Volts non RMS) for use by the igniter. If the correct voltage is shown, then place the red lead of the meter in contact with the pin on the power distribution board that is labeled "I/240" where the white wire with the black trace is connected (test point M). No voltage means that the wire between the power distribution board and the "IGN 240" connection on the ignition control is faulty. Check the connections or replace the power distribution board. If the correct voltage is detected, place the black lead of the meter in contact with the pin on the power distribution board that is labeled "ACN" where the red wire is connected (test point B). Place the red lead of the meter in contact with the pin on the power distribution board that is labeled "L2" where the red wire is connected (test point N). No voltage at this point means that the power distribution circuit board has shorted and needs to be

replaced. If the voltage is correct, move the red lead to the connection at the igniter wire quick disconnect (test point H). No voltage means that the wire between the power distribution board and the igniter test point H is faulty. Check the connections or replace the power distribution board. Place the red lead of the meter in contact with the pin on the power distribution board that is labeled "IGN" where the red wire is connected (test point P). The meter should show 196-253 Volts when the control is not energizing the igniter or 169-219 Volts RMS (147-192 non RMS) when the control is energizing the igniter. If the voltage measured is not within the range specified for the above conditions, then the power distribution board is shorted or open. Replace this component. If the correct voltage is measured at this point, move the red meter lead to the igniter wire quick disconnect (test point I). If the correct voltage as measured at test point P does not show here, the wire between the power distribution board and the igniter test point I is faulty. Check the connections or replace the power distribution board.

If your heater is connected to a 115 VAC supply, perform the following procedure. Place the black lead of the meter in contact with the pin on the power distribution board that is labeled "ACH" (test point C). Place the red lead of the meter in contact with the pin on the power distribution board that is labeled "L1" where the black wire is connected (test point J). The meter should read 98-126 VAC. If the meter shows voltage outside of this range, the power distribution circuit board has a loose connection or has shorted. Check the connections or replace the board. If the meter shows voltage within the range above, then move the red lead to the "L1" connection on the ignition control (test point K). Incorrect voltage here means that the wire between the power distribution board and the "L1" connection on the ignition control is faulty. Check the connections or replace the power distribution board. 98-126 Volts at test point K shows that voltage is getting to the ignition control. Now move the red meter lead to the "IGN 120" connection on the ignition control (test point Q). No voltage at this location during the trial for ignition means that the ignition control has failed and needs replacement. If the ignition control is working properly, it will pass the voltage, 98-126 Volts, for use by the igniter. If the correct voltage is shown, then place the red lead of the meter in contact with the pin on the power distribution board that is labeled "I/120" where the white wire with the yellow trace is connected (test point R). No voltage means that the wire between the power distribution board and the "IGN 120" connection on the ignition control is faulty. Check the connections or replace the power distribution board. If the voltage is 98-126 VAC, place the black lead of the meter in contact with the pin on the power distribution board that is labeled "ACN" where the red wire is connected (test point B). Place the red lead of the meter in



ELECTRONIC CONTROLLER

COMBUSTION CHAMBER PANEL

Wiring Diagram

— FACTORY WIRED 24V
 — FACTORY WIRED 120V/240 V

- BK -BLACK
- BK/Y -BLACK WITH YELLOW TRACE
- BL -BLUE
- BR -BROWN
- G -GREEN
- G/Y -GREEN WITH YELLOW TRACE
- GY -GRAY
- O -ORANGE
- PR -PURPLE
- R -RED
- W -WHITE
- W/BK -WHITE WITH BLACK TRACE
- W/R -WHITE WITH RED TRACE
- W/Y -WHITE WITH YELLOW TRACE
- Y -YELLOW

contact with the pin on the power distribution board that is labeled "L2" where the red wire is connected (test point N). No voltage at this point means that the power distribution circuit board has shorted and needs to be replaced. If the voltage is correct, move the red lead to the connection at the igniter wire quick disconnect (test point H). No voltage means that the wire between the power distribution board and the igniter test point H is faulty. Check the connections or replace the power distribution board. Place the red lead of the meter in contact with the pin on the power distribution board that is labeled "IGN" where the red wire is connected (test point P). The meter should show 98-126 Volts when the control is not energizing the igniter or zero volts when the control is energizing the igniter. If it does not, then the power distribution circuit board is shorted or open. Replace this component. If the correct voltage is measured at this point, move the red meter lead to the igniter wire quick disconnect (test point I). No voltage here during the trial for ignition means that the wire between the power distribution board and the igniter test point I is faulty. Check the connections or replace the power distribution board.

SECTION 11. Replacement Parts

11.1 Ordering Information


To order or purchase parts for the LX and LT Low NOx pool and spa heater, contact your nearest Jandy dealer or distributor. See the Jandy web site at www.jandy.com for the nearest service center. If they cannot supply you with what you need, contact Customer Service at Waterpik Technologies, P.O. Box 6000, Petaluma, California, 94954, Telephone (707) 776-8200 extension 245.

NOTE: To supply the correct part it is important that you state the model number, serial number and type of gas when applicable. This information is on the rating plate inside the heater.

11.2 Parts List

Key No.	Description	Model No.	Order Part No.	Key No.	Description	Model No.	Order Part No.
Water Components				Electrical (Continued)			
1	Complete Heat Exchanger (Copper)	250,400	R0326303,05	37	High Limits Set	All	R0023200
2	Tube Assy.(Cu), w/Hdwr & Gskts	250,400	R0326603,05	38	High Limit 135°F	All	R0022700
3	Heat Exchanger Baffles (Set of ten including end baffles)	250,400	R0334403,05	39	High Limits 150°F	All	R0023000
4	Front Header, w/Hdwr & Gskts	All	R0326900	40	Harness, High Limit Switch	All	R0334700
5	By-Pass Assy, w/Hdwr & Gskts	All	R0327100	41	Retainer Plates, High Limit (Set of 2)	All	R0336500
6	Gasket, Bypass Assy	All	R0336700	42	Hot Surface Ignitor	All	R0386900
7	Spring, Bypass	All	R0327200	43	Exhaust Temp. Limit Switch	All	R0329400
8	Coupling Nut Kit, w/Gasket, (Set of two)	All	R0327300	44*	Wire Harness Set Complete	All	R0397600
9	Gasket, Coupling, (Set of two)	All	R0327400	45*	Wire Harness, Power Transformer	All	R0330900
10	Rear Header, w/Hdwr & Gskts	All	R0327000	46*	Wire Harness, Ignition Control	All	R0331000
11	Gasket, Header (front or rear)	All	R0327500	47*	Wire Harness, Gas Valve	All	R0331100
12	Header Drain Plug w/Gasket(Set of 3)	All	R0335900	48*	Wire Harness, Safety Loop	All	R0331200
13*	Heat Exch. Hardware Kit & Gaskets	All	R0327600	49	Power Distribution Circuit Board	All	R0397500
Gas Components				50	Terminal Block for Fireman's Switch	All	R0097800
14	Burner Tray Assembly (Nat. Low Alt.)	250,400	R0386203,05	51	Temperature Control W/ Bezel, Gasket & Cover -LX Only	All	R0329600
14	Burner Tray Assembly (Nat. Mid Alt.)	250,400	R0394703,05	51*	Temperature Control W/ Bezel, Gasket & Cover -LT Only	All	R0350500
14	Burner Tray Assembly (Nat. Hi Alt.)	250,400	R0394803,05	52	Cover, Temperature Control	All	R0330600
14	Burner Tray Assembly (LP Low Alt.)	250,400	R0394503,05	53	Gasket, Temp Control/Top	All	R0387600
14	Burner Tray Assembly (LP Hi Alt.)	250,400	R0394603,05	54	Flame Sense Rod	All	R0387000
15	Burners (Ea.)	All	R0386400	55	Fusible Link	All	R0012200
16**	Manifold, Gas, Nat. (Low Altitude)	250,400	R0395003,05	56	Bracket, Fusible Link	All	R0337200
16**	Manifold, Gas, Nat. (Mid Altitude)	250,400	R0394303,05	Jacket Assy.			
16**	Manifold, Gas, Nat. (High Altitude)	250,400	R0394403,05	57	Door w/ Latch	250,400	R0387103,05
16**	Manifold, Gas, LP (Low Altitude)	250,400	R0394103,05	58	Door Latch Assembly w/ Handle	All	R0334900
16**	Manifold, Gas, LP (High Altitude)	250,400	R0394203,05	59	Cover Panel, Raceway	250,400	R0335103,05
17	Gas Valve Nat w/ Street Elbow	All	R0386600	60	Panel, Side, Lower (fits left or right)	All	R0330100
17	Gas Valve LP w/ Street Elbow	All	R0336900	61	Panel, Right Side, Upper	All	R0330200
Exhaust System				62	Cover Panel, Exhaust Switch	All	R0336600
18	Flue Collector	250,400	R0386703,05	63	Panel, Left Side, Upper	All	R0335200
19	Blower Assy.	All	R0329800	64	Cover Plate, I/O Header Side	All	R0335300
20	Gasket w/Blower Mntg Hdwr	All	R0329900	65	Cover Plate, Return Header Side	All	R0335400
21	Flue Vent Assy.	All	R0331500	66	Cover Panel, Left Side	All	R0335500
22	Indoor Vent Collar	250,400	R0331403,05	67	Rear Panel	250,400	R0330303,05
23	Outdoor Grill	All	R0328500	68	Corner Posts	All	R0330400
24*	Vent Hardware Kit	All	R0331600	69	Top Assy.	250,400	R0330503,05
Electrical				70	Combustion Chamber Assy.	250,400	R0387203,05
25	Transformer	All	R0061100	71	Base Panel	250,400	R0335608,10
26*	Fuse Assy, In-line	All	R0337100	Optional			
27	Blower Pressure Switch	All	R0302000	72*	Non Comb. Base	250,400	R0330803,05
28	Temperature Sensor w/Sleeve & Gskt	All	R0011800	73*	Touch-up Paint	All	R0335800
29	Gasket, Temperature Sensor	All	E0116400	74*	Temperature Rise Measurement Kit	All	R0336000
30	Plastic Sleeve, Temperature Sensor	All	10444900	75	Pressure Relief Valve	All	R0336100
31	Retainer Bracket, Temp. Sensor	All	10447300	76*	High Temp Silicone Sealant	All	R0382800
32	Screw, Retainer Bracket	All	F0009100	NOTES:			
33	Ignition Control	All	R0386800	1.	When ordering a kit for a model 250 specify as R#####-03, When ordering a kit for a model 400 specify as R#####-05,		
34	Pressure Switch Assy	All	R0334500	2.	All hardware sets contain all pieces necessary for assembly, including gaskets. Not shown.		
35	Pressure Switch, 2 psi	All	R0013200	3.	Gaskets and hardware are included in all kits that involve the removal of a gasket as part of the procedure to replace a part.		
36	Siphon Loop	All	R0334600	* PARTS NOT SHOWN ON KEY VIEW			
				** MANIFOLD KIT INCLUDES INSTALLED ORIFICES BUT DOES NOT INCLUDE GAS VALVE			

11.4 Detailed Exploded View



LIMITED WARRANTY

Thank you for purchasing Jandy® pool and spa products. Waterpik Technologies (manufacturer of Jandy products) warrants all parts to be free from manufacturing defects in materials and workmanship for a period of one year from the date of retail purchase, with the following exceptions:

- AquaLink® RS units installed with Jandy Surge Protection Kits will be covered for two years.
- NeverLube® valves are warranted for the life of pool and/or spa on which they were originally installed.

This warranty is limited to the first retail purchaser, is not transferable, and does not apply to products that have been moved from their original installation sites. The liability of Waterpik Technologies shall not exceed the repair or replacement of defective parts and does not include any costs for labor to remove and reinstall the defective part, transportation to or from the factory, and any other materials required to make the repair. This warranty does not cover failures or malfunctions resulting from the following:

1. Failure to properly install, operate or maintain the product(s) in accordance with our published Installation, Operation and Maintenance Manuals provided with the product(s).
2. The workmanship of any installer of the product(s).
3. Not maintaining a proper chemical balance in your pool and/or spa [pH level between 7.2 and 7.8, Total Alkalinity (TA) between 80 to 120 ppm, Total Dissolved Solids (TDS) less than 2000].
4. Abuse, alteration, accident, fire, flood, lightning, rodents, insects, negligence or acts of God.
5. Scaling, freezing, or other conditions causing inadequate water circulation.
6. Operating the product(s) at water flow rates outside the published minimum and maximum specifications.
7. Use of non-factory authorized parts or accessories in conjunction with the product(s).
8. Chemical contamination of combustion air or improper use of sanitizing chemicals, such as introducing sanitizing chemicals upstream of the heater and cleaner hose or through the skimmer.
9. Overheating, incorrect wire runs; improper electrical supply; collateral damage caused by failure of O-Rings, DE grids, or cartridge elements; or damage caused by running the pump with insufficient quantities of water.

LIMITATION OF LIABILITY:

This is the only warranty given by Waterpik Technologies. No one is authorized to make any other warranties on Waterpik Technologies' behalf. **THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND MERCHANTABILITY. WATERPIK TECHNOLOGIES EXPRESSLY DISCLAIMS AND EXCLUDES ANY LIABILITY FOR CONSEQUENTIAL, INCIDENTAL, INDIRECT OR PUNITIVE DAMAGES FOR BREACH OF ANY EXPRESSED OR IMPLIED WARRANTY.** This warranty gives you specific legal rights. You may also have other rights which vary by state or province.

WARRANTY CLAIMS:

For prompt warranty consideration, contact your dealer and provide the following information: proof of purchase, model number, serial number and date of installation. The installer will contact the factory for instructions regarding the claim and to determine the location of the nearest designated service center. If the dealer is not available, you can locate a service center in your area by visiting www.jandy.com or by calling our technical support department at (707) 776-8200 extension 260. All returned parts must have a Returned Material Authorization number to be evaluated under the terms of this warranty.

H0256100E

The Jandy logo features the word "Jandy" in a large, serif font with a stylized wave graphic underneath the letters "y" and "d".

6000 Condor Drive, Moorpark, CA, USA 93021 • 707.776.8200 FAX 707.763.7785

A Waterpik Technologies Company

Litho in U.S.A. © Waterpik Technologies Inc. 0506